Whirlpool CSP2771HW0 06 - 3401797 BURNER ASSEMBLY



Whirlpool Commercial Whirlpool CSP2771HW0 Dryer Parts Parts Diagram 06 - 3401797 BURNER ASSEMBLY
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3401797	285904		Burner-Gas
2	688617	693140		Burner
3	694298			Bracket, Ignitor
4	686590	279311		Ignitor
5	3393909			Screw, 8-32 X 7/8
6	343641	681414		Screw, 10AB X 1/2
7	3389871		Not Available	Base, Burner
8	3387057			Screw, 10-16 X 1/2 Orifice, Burner
9	3397656			Orifice, Burner
"	15775	72017		Paint, Touch-Up
10	3401775	279923		NAT Gas
11	694421			Screw, Bracket Mounting
12	694538			Bracket, Shunt
13	694540			Coil, 60 Hz
14	694539			Coil, 60 Hz
15	694424			Leak, Limiter

16	694423			Screw, Regulator Adjustment
17	694422			Spring, Regulator
20	239822	W10295523		Plug, Pipe
21	3387224		Not Available	Pipe, Gas Supply
22	697441			Valve And Union Shut-Off
23	3393767			Pipe, Tail
24	233076			Nut, Compression
25	3387561			Clamp-Pipe
26	3389889			Bracket, Support
"	694572	49572A		Conversion Kit To Type L.p.g.f

the laundry company®
the laundry company®
the laundry company®