Washer-Extractor

Refer to Page 5 for Model Numbers






Table of Contents

Title	Page
Parts Ordering Information	9
Serial Plate Location	
Model Identification	
Product Overview - PS40 Control	
Decals - Models through 8/31/09 (Drawing 1 of 2)	
Decals - Models through 8/31/09 (Drawing 1 of 2)	
Decals - Models starting 9/1/09	
Bearing Housing Assembly (Drawing 1 of 6)	
Bearing Housing Assembly (Drawing 2 of 6)	
Bearing Housing Assembly (Drawing 3 of 6)	
Bearing Housing Assembly (Drawing 4 of 6)	
Bearing Housing Assembly (Drawing 5 of 6)	
Bearing Housing Assembly (Drawing 6 of 6)	
Top and Front Panels (Drawing 1 of 2)	
Top and Front Panels (Drawing 2 of 2)	
Rear, Side and Valve Panels (Drawing 1 of 2)	
Rear, Side and Valve Panels (Drawing 2 of 2)	
Control Box Assembly	
Cylinder Assembly	
Single Cup Dispenser Assembly	
5 Cup Dispenser Assembly	
Door Assembly - Models through 2/9/09 (Drawing 1 of 2)	42
Door Assembly - Models through 2/9/09 (Drawing 2 of 2)	44
Door Assembly - Models starting 2/10/09 (Drawing 1 of 2)	46
Door Assembly - Models starting 2/10/09 (Drawing 2 of 2)	48
Door Lock Assembly	50
Door Lock Assembly with Magnetic Sensor	52
5 Cup Hot Plumbing Assembly	54
1 Cup Hot Plumbing Assembly	56
5 Cup Cold Plumbing Assembly	58
1 Cup Cold Plumbing Assembly	60
Auxiliary Plumbing Assembly	62
Supply Hose and Filter (Optional)	64
Steam Heat Assembly	
Steam Option Assembly	
Shell Assembly (Drawing 1 of 2)	
Shell Assembly (Drawing 2 of 2)	
Electric Heat Shell Assembly (Drawing 1 of 2)	
Electric Heat Shell Assembly (Drawing 2 of 2)	
Drive Box Assembly	
Electric Heat Drive Box Assembly	80

© Copyright 2023, Alliance Laundry Systems LLC

All rights reserved. No part of the contents of this book may be reproduced or transmitted in any form or by any means without the expressed written consent of the publisher.

AC Drive and EMI Filter	82
AC Drive and EMI Filter - Electric Heat Models	84
PowerFlex Drive and EMI Filter - Design 1 Models	86
PowerFlex Drive and EMI Filter - Design 2 Models	88
Main Assembly (Drawing 1 of 8)	90
Main Assembly (Drawing 2 of 8)	92
Main Assembly (Drawing 3 of 8)	94
Main Assembly (Drawing 4 of 8)	96
Main Assembly (Drawing 5 of 8)	98
Main Assembly (Drawing 6 of 8)	100
Main Assembly (Drawing 7 of 8)	102
Main Assembly (Drawing 8 of 8)	104
Parts Index	107

Parts Ordering Information


If literature or replacement parts are required, contact the source from whom the machine was purchased or contact Alliance Laundry Systems at (920) 748-3950 for the name and address of the nearest authorized parts distributor.

For technical assistance, call the number listed below:

(920) 748-3121 Ripon, Wisconsin

Serial Plate Location

When calling or writing about your product, be sure to mention model and serial numbers. Model and serial numbers are located on serial plate(s) as shown. The serial plate is located inside the door and on the upper rear panel.




Notes


Model Identification

Information in this manual is applicable to these washer-extractor models:

	• •	
CP040PHN1	IP040PHN1	JP040PHN1
CP040PHQ1	IP040PHN2	JP040PHQ1
CP040PHX2	IP040PHQ1	JP060PHN1
CP040PMN1	IP040PHX2	JP060PHN2
CP040PMQ1	IP040PMN1	JP060PHQ1
CP040PMX2	IP040PMQ1	JP060PMQ1
CP060PHN1	IP040PMX2	
CP060PHN2	IP060PHN1	
CP060PHQ1	IP060PHN2	
CP060PHQ2	IP060PHQ1	
CP060PHX1	IP060PHQ2	
CP060PHX2	IP060PHX2	
CP060PMN1	IP060PMN1	
CP060PMQ1	IP060PMN2	
CP060PMX2	IP060PMQ1	
CPC40H	IP060PMX2	
CPC40M	IPH40H	
CPC60H	IPH40M	
CPC60M	IPH60H	
	IPH60M	
	IPH180	
	IPH270	

Product Overview - PS40 Control






PHM3091P_C002874

Product Overview - PS40 Control

1 Product Family CP IP JP 2 Capacity (Pounds) 040 060 080 100 125 140 175 3 Control P (PS-40 Control) 4 Speed H (High Speed) M (Medium Speed) M (Medium Speed) M (Medium Speed) M (208-220/220-240/50/60/3) X (208-220/220-240/50/60/13) 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	REF	PART NO.	DESCRIPTION	COMMENTS
JP	1		Product Family	
2 Capacity (Pounds) 040 060 080 100 125 140 175 3 Control P (PS-40 Control) 4 Speed H (High Speed) M (Medium Speed) M (Medium Speed) S Voltage N (380-415/440-480/50/60/3) Q (208-220/220-240/50/60/3) X (208-220/220-240/50/60/1/3) 6 Design 1 2 7 Heat 0 (Prep for Steam) D (Direct) E (Electric) 8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 5 (5 Compartments 12 Signals) 5 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals) 7 (No Compartment 6 Signals) 7 (No Compartment 6 Signals)				•
060				
080 100 125 140 175 140 175 140 175 140 175 140 175 140 175 140 175 140 175 140 175 140 175	2		Capacity (Pounds)	* * *
100 125 140 175 175 180 175 180				
125 140 175				
140				
175 3				
Speed				
## Speed ## (High Speed) ## (Medium Speed) ## (Med				
M (Medium Speed) 5	3		Control	P (PS-40 Control)
5 Voltage N (380-415/440-480/50/60/3) Q (208-220/220-240/50/60/3) X (208-220/220-240/50/60/1/3) 6 Design 1 7 Heat 0 (Prep for Steam) D (Direct) E (Electric) 8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 2 valves) C (Metric Thread - 2 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartments 6 Signals) 5 (5 Compartments 6 Signals) 5 (5 Compartments 12 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartments 12 Signals)	4		Speed	H (High Speed)
Q (208-220/220-240/50/60/3) X (208-220/220-240/50/60/1/3) 6 Design 1 2 7 Heat 0 (Prep for Steam) D (Direct) E (Electric) 8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 3 valves) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 5 (5 Compartments 12 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				M (Medium Speed)
Q (208-220/220-240/50/60/3) X (208-220/220-240/50/60/1/3) 6 Design 1 2 7 Heat 0 (Prep for Steam) D (Direct) E (Electric) 8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 3 valves) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 5 (5 Compartments 12 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)	5		Voltage	N (380-415/440-480/50/60/3)
6 Design 7 Heat 0 (Prep for Steam) D (Direct) E (Electric) 8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartments 6 Signals) 5 (5 Compartments 12 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)			•	Q (208-220/220-240/50/60/3)
7 Heat O (Prep for Steam) D (Direct) E (Electric) 8 Plumbing O (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 12 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				X (208-220/220-240/50/60/1/3)
7 Heat O (Prep for Steam) D (Direct) E (Electric) 8 Plumbing O (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 12 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)	6		Design	1
D (Direct) E (Electric) 8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)			G	2
B Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)	7		Heat	0 (Prep for Steam)
8 Plumbing 0 (Standard US Thread - 2 valves) A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				D (Direct)
A (US Thread - 3 valves) B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				E (Electric)
B (Metric Thread - 2 valves) C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)	8		Plumbing	0 (Standard US Thread - 2 valves)
C (Metric Thread - 3 valves) D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)			•	A (US Thread - 3 valves)
D (US Thread - 2 valves, 3 inlets) E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				B (Metric Thread - 2 valves)
E (No valves) 9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				C (Metric Thread - 3 valves)
9 Supply 1 (1 Compartment 6 Signals) 2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				
2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				E (No valves)
2 (1 Compartment 12 Signals) 5 (5 Compartments 6 Signals) 6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)	9		Supply	
6 (5 Compartments 12 Signals) 7 (No Compartment 6 Signals)				
7 (No Compartment 6 Signals)				
8 (No Compartment 12 Signals)				
- (ita damparanana 12 digitala)				8 (No Compartment 12 Signals)

Decals - Models through 8/31/09 (Drawing 1 of 2)




PHM2767P_C002874

Decals - Models through 8/31/09 (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
1	F200085100	Spin Warning Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
2	F200085000R1	Hot Surface Warning Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1 and IP060PMQ1
3	F200085300	Hot Water and Chemical Caution Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1 and JP060PHQ1
4	F200318200R1	Cover Decal	
5	F230734	Water Line Caution Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
6	F0231367-00R3	Hot Water Valve Decal	
7	F0231368-00R4	Cold Water Valve Decal	
8	C000508R1	Bearing Lubrication Decal	
9	C000506	Supply Signal Decal	
10	F230917-1	External Supply Connection Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PMQ1, IP040PHN1, IP040PHQ1, IP060PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1

Decals - Models through 8/31/09 (Drawing 2 of 2)



PHM2767PA_C002874


Decals - Models through 8/31/09 (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
1	F200318200R1	Cover Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1 and IP060PMQ1
2	D502511R3	Electrical Shock Label	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
3	D500049R4	Warning Label	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
4	N/A	Crush Hazard Warning Decal	Models CPC40H, CPC40M, CPC60H, CPC60M, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
	D502506R3	Pinched Fingers Label	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
5	F200085000R1	Hot Surface Warning Decal	Models CPC40H, CPC40M, CPC60H, CPC60M, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
	F231380	Hot Surface Warning Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1
6	C001038	Logo Decal	Models IP040PHN1, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270
7	C000694	Door Release Decal	
8	F230303R2	Push Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, IP040PMN1, IP040PMQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1

N/A = Part no longer available

Decals - Models starting 9/1/09

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHQ1 and JP060PMQ1




PHM3089P_C002874

Decals - Models starting 9/1/09

REF	PART NO.	DESCRIPTION	COMMENTS
1	C000694	Door Release Decal	
2	F230303R2	Push Decal	
3	F200085100	Spin Warning Decal	All models except JP040PHQ1, JP060PHQ1 and JP060PMQ1
4	F200085000 R1	Hot Surface Warning Decal	
5	F200085300	Hot Water and Chemical Caution Decal	
6	F8614301	Hot Surface Warning Label	Steam models only
7	F8246401	Mount On Concrete Warning Label	
8	F200061000	Clean Filter Daily Decal	
9	C000508R1	Bearing Lubrication Decal	
10	F8150201	External Supply Connection Decal	
11	F8233501	Warning Label	
12	F8115501	Electric Shock Danger Label	
13	44324001	Warning Label	

Bearing Housing Assembly (Drawing 1 of 6) Models CPC40H, CPC60H, IPH40H and IPH60H

Models Through 3/23/04




PHM2768P_C002874

Bearing Housing Assembly (Drawing 1 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000147	Washer	8 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C001018	Screw	8 required; Bearing housing to frame; Models CPC40H and IPH40H
	C000145	Screw	8 required; Bearing housing to frame; Models CPC60H and IPH60H
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	F200201	Hose Clamp	2 required; Ship inside machine
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
1	C000058P	Bearing Housing Assembly	Includes items 2 and 4-20
2	J1408004	Connector	
3	212/00022/00P	Lubricator	Optional; Not installed
4	C000372	Mounting Bracket	
5	C001649	Reducing Connector	
6	C000068	Cylinder Shaft	
7	C000151	Carb Bearing	
8	C000064	Grease Shield	
9	C000152	Roller Bearing	
10	C000071	Washer	
11	C000063	Nut	
12	C000158	Seal Plate	
13	C000070	V-Ring Seal	
14	C000057	Bearing Housing	
15	C002959	Triple Lip Seal	
16	C000069	V-Ring Seal	
17	C000065	Seal Plate	
18	C000066	Seal Plate	
19	C001916	Plate	
20	C001704	Gasket	

Bearing Housing Assembly (Drawing 2 of 6) Models CPC40H, CPC60H, IPH40H and IPH60H

Models Starting 3/23/04



PHM2971P_C002874


Bearing Housing Assembly (Drawing 2 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000147	Washer	8 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C001018	Screw	8 required; Bearing housing to frame; Models CPC40H and IPH40H
	C000145	Screw	8 required; Bearing housing to frame; Models CPC60H and IPH60H
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000058P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
	C001364P	Bearing Housing Assembly	Includes items 2 and 5; Viton seals
2	J1408004	Connector	
3	212/00022/00P	Lubricator	Optional; Not installed
4	C000372	Mounting Bracket	
5	C001649	Reducing Connector	

Bearing Housing Assembly (Drawing 3 of 6)

Models CPC40M, CPC60M, IPH40M, IPH60M, IPH180 and IPH270

Models Through 3/23/04



PHM2769P_C002874


Bearing Housing Assembly (Drawing 3 of 6)

C001019 Screw 8 required; Bearing housing to frame; Models CPC40M, IPH40M and IPH180	
CPC60M, IPH60M and IPH270	
F430929 Screw 12 required; Front and rear seal plates to bear housing C000571 Washer 12 required; Front and rear seal plates to bear housing C002637P Proximity Switch Assembly 1 required; Proximity switch on bearing housing C000552 Hose 25 inch; Weep hole fitting to drain line fitting C000628P Tubing 2 required; 25 inch; Lube fittings to bearing housing 36801 Hose Clamp 1 required; Bearing weep hole "TEE" 1 C000728P Bearing Housing Assembly Includes items 2 and 4-21 2 J1408004 Connector 3 212/00022/00P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
Nousing C000571 Washer 12 required; Front and rear seal plates to bear housing	
Nousing C002637P Proximity Switch Assembly 1 required; Proximity switch on bearing housing C000552 Hose 25 inch; Weep hole fitting to drain line fitting C000628P Tubing 2 required; 25 inch; Lube fittings to bearing housing 36801 Hose Clamp 1 required; Bearing weep hole "TEE" 1 C000728P Bearing Housing Assembly Includes items 2 and 4-21 2 J1408004 Connector Connect	ng
C000552 Hose 25 inch; Weep hole fitting to drain line fitting C000628P Tubing 2 required; 25 inch; Lube fittings to bearing hole 36801 Hose Clamp 1 required; Bearing weep hole "TEE" 1 C000728P Bearing Housing Assembly Includes items 2 and 4-21 2 J1408004 Connector 3 212/00022/00P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	ng
C000628P Tubing 2 required; 25 inch; Lube fittings to bearing hor 36801 Hose Clamp 1 required; Bearing weep hole "TEE" 1 C000728P Bearing Housing Assembly Includes items 2 and 4-21 2 J1408004 Connector 3 212/00022/00P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	J
36801	
1 C000728P Bearing Housing Assembly Includes items 2 and 4-21 2 J1408004 Connector 3 212/00022/00P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	sing
2 J1408004 Connector 3 212/00022/00P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
3 212/00022/00P Lubricator Optional; Not installed 4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
4 C000372 Mounting Bracket 5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
5 C001649 Reducing Connector 6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
6 C000725 Bearing Housing 7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
7 C000485 Carb Bearing 8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
8 C000729 Front Grease Shield 9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
9 C000730 Rear Grease Shield 10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
10 C000486 Roller Bearing 11 C000488 Washer 12 C000727 Seal Plate	
11 C000488 Washer 12 C000727 Seal Plate	
12 C000727 Seal Plate	
40 0000700 Oddindan Oba#	
13 C000726 Cylinder Shaft	
14 C000731 V-Ring Seal	
15 C000487 Nut	
16 C002959 Triple Lip Seal	
17 C000069 V-Ring Seal	
18 C000065 Seal Plate	
19 C000066 Seal Plate	
20 C001916 Plate	
21 C001704 Gasket	

Bearing Housing Assembly (Drawing 4 of 6)

Models CPC40M, CPC60M, IPH40M, IPH60M, IPH180 and IPH270

Models Starting 3/23/04




PHM2972P_C002874

Bearing Housing Assembly (Drawing 4 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001019	Screw	8 required; Bearing housing to frame; Models CPC40M, IPH40M and IPH180
	C001018	Screw	8 required; Bearing housing to frame; Models CPC60M, IPH60M and IPH270
	C000147	Washer	16 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000728P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
2	J1408004	Connector	
3	212/00022/00P	Lubricator	Optional; Not installed
4	C001037	Mounting Bracket	
5	C001649	Reducing Connector	

Bearing Housing Assembly (Drawing 5 of 6)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ1, CP060PHX1, CP060PHX2, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IPH270, JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHN2 and JP060PHQ1




PHM2971P_C002874

Bearing Housing Assembly (Drawing 5 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000147	Washer	8 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C001018	Screw	8 required; Bearing housing to frame; Models CP040PHN1, CP040PHQ1, IP040PHN1, IP040PHQ1 and JP040PHN1
	C000145	Screw	8 required; Bearing housing to frame; Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2 and JP060PHQ1
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	F200201	Hose Clamp	2 required; Ship inside machine; Models through 3/23/04
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000058P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
	C001364P	Bearing Housing Assembly	Includes items 2 and 5; Viton seals
2	J1408004	Connector	
3	212/00022/00P	Lubricator	Optional; Not installed
4	C000372	Mounting Bracket	
5	C001649	Reducing Connector	

Bearing Housing Assembly (Drawing 6 of 6) Models CP040PMN1, CP040PMQ1, CP040PMX2, CP060PMN1, CP060PMQ1,

Models CP040PMN1, CP040PMQ1, CP040PMX2, CP060PMN1, CP060PMQ1, CP060PMX2, IP040PMN1, IP040PMQ1, IP040PMX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH270 and JP060PMQ1




PHM2972P_C002874

Bearing Housing Assembly (Drawing 6 of 6)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001019	Screw	8 required; Bearing housing to frame; Models CP040PMN1, CP040PMQ1, IP040PMN1 and IP040PMQ1
	C001018	Screw	8 required; Bearing housing to frame; Models CP060PMN1, CP060PMQ1, IP060PMN1, IP060PMQ1, IPH270 and JP060PMQ1
	C000147	Washer	16 required; Bearing housing to frame
	F430929	Screw	12 required; Front and rear seal plates to bearing housing
	C000571	Washer	12 required; Front and rear seal plates to bearing housing
	C002637P	Proximity Switch Assembly	1 required; Proximity switch on bearing housing
	C002959	Triple Lip Seal	
	C000552	Hose	25 inch; Weep hole fitting to drain line fitting
	C000628P	Tubing	2 required; 25 inch; Lube fittings to bearing housing
	36801	Hose Clamp	1 required; Bearing weep hole "TEE"
	1390P	Bearing Housing Puller Kit	Purchase
	1390-1	Bearing Housing Puller Kit	Rental; Requires C002023 Hardware Kit
	C002023	Hardware Kit	Use with Rental 1390-1 Bearing Housing Puller Kit
1	C000728P	Bearing Housing Assembly	Includes items 2 and 5; Standard seals
	C002032P	Bearing Housing Assembly	Includes items 2 and 5; Viton seals
2	J1408004	Connector	
3	212/00022/00P	Lubricator	Optional; Not installed
4	C001037	Mounting Bracket	
5	C001649	Reducing Connector	

Top and Front Panels (Drawing 1 of 2)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM2945P_C002874

Top and Front Panels (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	2 required for top panel to valve panel; 12 required for front panel to side panel; 2 required for lower front panel to frame; 4 or 5 required for front electrical mounting bracket to side panel
	F431024	Nut	4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel
	N/A	Nut	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000571	Washer	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000585	Washer	2 required for lower front panel to frame
	F430910	Screw	6 required for rub rails to lower front panel; Models starting 3/23/04
	C000568	Nut	6 required for rub rails to lower front panel; Models starting 3/23/04
1	C000483	Control Panel Insert	
2	C000513P	Top Panel	
3	C000484	Control Panel Insert	
4	C002967P	Front Panel Assembly	5 compartment
	C002966	Front Panel Assembly	1 compartment
5	C002984	Lower Front Adjustment Bracket Assembly	Models starting 3/23/04
6	C001013	Insert Rail	Models starting 3/23/04
7	C001012	Rub Rail	Vinyl; Models starting 3/23/04
8	N/A	Lower Front Panel	Models through 3/23/04
	C001246	Front Panel	Models starting 3/23/04
9	C000629	Trim Gasket	Black; 10 feet; Models starting 3/23/04
10	1242	Programming Key	
11	C003024P	Keymode Switch Assembly	
12	F200233500	Emergency Stop Pushbutton	
13	F200233700P	Emergency Stop Button Kit	Includes items 12 and 14
14	F200233401P	Contact Block Switch	Includes F8069501 Contact Switch and F8538101 Contact Base
	F8069501	Contact Switch	
	F8538101	Contact Base	

N/A = Part no longer available

Top and Front Panels (Drawing 2 of 2)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1




Top and Front Panels (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	2 required for top panel to valve panel; 12 required for front panel to side panel; 2 required for lower front panel to frame; 4 or 5 required for front electrical mounting bracket to side panel
	F431024	Nut	4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel
	N/A	Nut	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000571	Washer	2 required for top panel to valve panel; 2 required for lower front panel to frame
	C000585	Washer	2 required for lower front panel to frame
	F430910	Screw	6 required for rub rails to lower front panel
	C000568	Nut	6 required for rub rails to lower front panel
1	C000484	Control Panel Insert	
2	C000050	Top Panel	
3	C000483	Control Panel Insert	
4	C002968	Front Panel Assembly	1 compartment
	C002969	Front Panel Assembly	5 compartment
5	N/A	Lower Front Panel	Models through 3/23/04
	C001248	Front Panel	Models starting 3/23/04
6	C002985	Lower Front Adjustment Bracket Assembly	Models starting 3/23/04
7	C000636	Insert Rail	
8	C000633	Rub Rail	Vinyl
9	1242	Programming Key	
10	C003024P	Keymode Switch Assembly	
11	F200233500	Emergency Stop Pushbutton	
12	C000629	Trim Gasket	Black; 11 feet; Models starting 3/23/04
13	F200233401P	Contact Block Switch	

N/A = Part no longer available

Rear, Side and Valve Panels (Drawing 1 of 2) Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H,

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM2770PA_C002874

Rear, Side and Valve Panels (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	6 required for valve panel to side panel; 2 required for top panel to valve panel; 12 required for front panel to side panel; 6 required for side panel to frame; 4 required for rear cover to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel
	F431024	Nut	6 required for valve panel to side panel; 4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel
	N/A	Nut	2 required for top panel to valve panel; 6 required for side panel to frame; 2 required for rear electrical cover to valve panel
	C000571	Washer	2 required for top panel to valve panel; 6 required for side panel to frame; 4 required for rear cover to side panel
	C000585	Washer	6 required for side panel to frame
	F430929	Screw	2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel
1	C002696	Side Panel and Stiffener Assembly	
2	C000533	Front Electrical Enclosure Rail	
3	C000539	Grease Connector Box	
4	C000173	Rear Electrical Enclosure Cover	
5	N/A	Inlet Power Cover	Models through 3/23/04
	C001257	Inlet Power Cover	Models starting 3/23/04
6	C002979	Valve Panel Assembly	
7	C000525	Rear Panel	
8	C002695	Side Panel and Stiffener Assembly	
9	N/A	Side Skirt Panel	Models through 3/23/04
10	C000530	Front Skirt Panel	Models through 3/23/04

N/A = Part no longer available

Rear, Side and Valve Panels (Drawing 2 of 2)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1




PHM2771PA_C002874

Rear, Side and Valve Panels (Drawing 2 of 2)

C000567 Screw 6 required for valve panel; 2 required for top panel to valve panel; 12 required for front panel to side panel; 6 required for side panel to frame; 4 required for rear cover to side panel; 3 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel F431024 Nut 6 required for valve panel to side panel; 4 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel N/A Nut 2 required for top panel to valve panel; 6 required for side panel to frame; 2 required for rear electrical cover to valve panel C000571 Washer 2 required for top panel to valve panel; 6 required for side panel to frame; 4 required for rear cover to side panel C000585 Washer 6 required for side panel to frame F430929 Screw 2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel; 1 required for inlet power cover to valve panel 1 C002708 Side Panel and Stiffener Assembly Right 2 C000218 Front Electrical Enclosure Rail 3 C000539 Grease Connector Box 4 C000173 Rear Electrical Enclosure Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left	REF	PART NO.	DESCRIPTION	COMMENTS
front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box to valve panel N/A Nut 2 required for top panel to valve panel; 6 required for side panel to frame; 2 required for rear electrical cover to valve panel C000571 Washer 2 required for top panel to valve panel; 6 required for side panel to frame; 4 required for rear cover to side panel C000585 Washer 6 required for side panel to frame F430929 Screw 2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel 1 C002708 Side Panel and Stiffener Assembly Right 2 C000218 Front Electrical Enclosure Rail 3 C000539 Grease Connector Box 4 C000173 Rear Electrical Enclosure Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left		C000567	Screw	panel to valve panel; 12 required for front panel to side panel; 6 required for side panel to frame; 4 required for rear cover to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for grease box
panel to frame; 2 required for rear electrical cover to valve panel C000571 Washer 2 required for top panel to valve panel; 6 required for side panel to frame; 4 required for rear cover to side panel C000585 Washer 6 required for side panel to frame F430929 Screw 2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel 1 C002708 Side Panel and Stiffener Assembly Right 2 C000218 Front Electrical Enclosure Rail 3 C000539 Grease Connector Box 4 C000173 Rear Electrical Enclosure Cover 5 N/A Inlet Power Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left		F431024	Nut	front panel to side panel; 4 or 5 required for front electrical mounting bracket to side panel; 2 required for
panel to frame; 4 required for rear cover to side panel		N/A	Nut	panel to frame; 2 required for rear electrical cover to
F430929 Screw 2 required for rear electrical cover to valve panel; 1 required for inlet power cover to valve panel Right 1 C002708 Side Panel and Stiffener Assembly Right 2 C000218 Front Electrical Enclosure Rail 3 C000539 Grease Connector Box 4 C000173 Rear Electrical Enclosure Cover 5 N/A Inlet Power Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left		C000571	Washer	
required for inlet power cover to valve panel 1		C000585	Washer	6 required for side panel to frame
2 C000218 Front Electrical Enclosure Rail 3 C000539 Grease Connector Box 4 C000173 Rear Electrical Enclosure Cover 5 N/A Inlet Power Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left		F430929	Screw	·
3 C000539 Grease Connector Box 4 C000173 Rear Electrical Enclosure Cover 5 N/A Inlet Power Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left	1	C002708	Side Panel and Stiffener Assembly	Right
4 C000173 Rear Electrical Enclosure Cover 5 N/A Inlet Power Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left	2	C000218	Front Electrical Enclosure Rail	
5 N/A Inlet Power Cover Models through 3/23/04 C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left	3	C000539	Grease Connector Box	
C001257 Inlet Power Cover Models starting 3/23/04 6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left	4	C000173	Rear Electrical Enclosure Cover	
6 C002980 Valve Panel Assembly 7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left	5	N/A	Inlet Power Cover	Models through 3/23/04
7 C000051 Rear Panel 8 C002707 Side Panel and Stiffener Assembly Left		C001257	Inlet Power Cover	Models starting 3/23/04
8 C002707 Side Panel and Stiffener Assembly Left	6	C002980	Valve Panel Assembly	
`	7	C000051	Rear Panel	
	8	C002707	Side Panel and Stiffener Assembly	Left
9 N/A Side Skirt Panel Models through 3/23/04	9	N/A	Side Skirt Panel	Models through 3/23/04
10 C000314 Front Skirt Panel Models through 3/23/04	10	C000314	Front Skirt Panel	Models through 3/23/04

N/A = Part no longer available

Control Box Assembly




Control Box Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F431133	Washer	4 required for keypad to keypad mounting plate; Models starting 3/23/04
	F430910	Screw	4 required for keypad to keypad mounting plate
	C000567	Screw	1 required for keypad mounting plate to control panel; 4 required for electrical box to mounting bracket
	F431024	Nut	1 required for keypad mounting plate to control panel
	N/A	Nut	4 required for electrical box to mounting bracket
	C000571	Washer	4 required for electrical box to mounting bracket
	F430909	Screw	2 required for electrical box cover to electrical box; 1 required for ground connection to electrical box for models through 03/23/04; 2 required for ground connection to electrical box for models starting 3/23/04
	C000865	Control Module Harness	
	210/00902/00P	Infrared Cable	
1	C000432	Front Electrical Enclosure Assembly	
2	C000348	Front Electrical Enclosure Cover	
3	C001276	Control Panel Decal	Models IP040PHN1, IP040PHN2, IP040PHQ1, IP040PMN1, IP040PMQ1, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IPH180, IPH270, IPH40H, IPH40M, IPH60H and IPH60M
	C001389	Control Panel Decal	Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CPC40H, CPC40M, CPC60H and CPC60M
	C001069	Control Panel Decal	Models JP040PHN1, JP040PHQ1, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1
4	C000282P	Keypad Controller	
5	C000376	Standoff	8 required for keypad to keypad mounting plate
6	C000375	Mounting Bracket	
7	C000281P	Main Board Controller Kit	Includes item 9
8	209/00505/04P	Battery	
9	C002642P	Tilt Switch Assembly	
10	C000371P	Chemical Supply Controller	
11	C000213	Front Electrical Enclosure	
12	C002999	RC Network Assembly	
13	F330217P	RC Network Filter	

N/A = Part no longer available

Cylinder Assembly




Cylinder Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000583	Washer	Models starting 3/23/04
1	N/A	Washer	Models through 3/23/04
	C001239	Washer	Models starting 3/23/04
2	C001238	Cylinder Bolt Shroud	Models starting 3/23/04
3	N/A	Bolt	Models through 3/23/04
	C001093	Screw	Models starting 3/23/04 and continuing through 7/1/06
	C001294	Screw	Models starting 7/1/06
4	C000455P	Cylinder Assembly Kit	Models CP040PHN1, CP040PHQ1, CP040PHX2, CPC40H, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IPH40H, JP040PHN1 and JP040PHQ1
	C000812P	Cylinder Assembly Kit	Models CP040PMN1, CP040PMQ1, CP040PMX2, CPC40M, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40M and IPH180
	C000792P	Cylinder Assembly Kit	Models CP060PMN1, CP060PMQ1, CP060PMX2, CPC60M, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60M, IPH270 and JP060PMQ1; Includes lifter rod
	C000037P	Cylinder Assembly Kit	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CPC60H, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IPH60H, JP060PHN1, JP060PHN2 and JP060PHQ1; Includes lifter rod
5	F431011	Nut	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270 and JP060PHQ1 starting 3/23/04
6	F0431159-00	Washer	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M and IPH270 starting 3/23/04
7	C001327	Cylinder Lifter Rod	Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270 and JP060PHQ1 starting 3/23/04

N/A = Part no longer available

Single Cup Dispenser Assembly




PHM2773P_C002874

Single Cup Dispenser Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F430920	Screw	4 required for hinges to cover and 4 required for hinges to control panel for models through 3/23/04; 2 required for dispenser cover to handle for models starting 3/23/04
	C001148	Screw	4 required for hinges to cover; 4 required for hinges to control panel; Models starting 3/23/04
	F430909	Screw	2 required for dispenser cover to handle; Models through 3/23/04
	F430925	Screw	2 required for dispenser to control panel
	N/A	Nut	2 required for dispenser to control panel
	F200201	Hose Clamp	2 required for dispenser hose
	C000552	Hose	Flush hose for supply dispenser
1	C000052	Supply Dispenser Cup	23 ounce
2	C001007	Siphon Tube	
3	C001788	Dispenser Door Handle	
4	C000605	Single Front Dispenser Cover	
5	N/A	Lift-Off Hinge	Nylon; Models through 3/23/04
	C001787	Hinge	Nylon; Black; Models starting 3/23/04
6	C001017	Front Supply Dispenser Nozzle	
7	C000220	Single Dispenser Assembly	1 cup

N/A = Part no longer available

5 Cup Dispenser Assembly



PHM2774P_C002874


5 Cup Dispenser Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F430920	Screw	4 required for hinges to cover and 4 required for hinges to control panel for models through 3/23/04; 2 required for dispenser cover to handle for models starting 3/23/04
	C001148	Screw	4 required for hinges to cover; 4 required for hinges to control panel; Models starting 3/23/04
	F430909	Screw	2 required for dispenser cover to handle; Models through 3/23/04
	F430925	Screw	2 required for dispenser to control panel
	N/A	Nut	2 required for dispenser to control panel
	36801	Hose Clamp	12 required for 5 cup supply dispenser for models through 3/23/04; 7 required for 5 cup supply dispenser for models starting 3/23/04
	C001004	Spring Hose Clamp	5 required for 5 cup supply dispenser; Models starting 3/23/04
	F200201	Hose Clamp	2 required for dispenser hose
	C000552	Hose	Flush hose for supply dispenser cups
1	C001007	Siphon Tube	
2	C001788	Dispenser Door Handle	
3	C000606	Front Cover	5 compartment
4	N/A	Lift-Off Hinge	Nylon; Models through 3/23/04
	C001787	Hinge	Nylon; Black; Models starting 3/23/04
5	C001017	Front Supply Dispenser Nozzle	
6	C000053	Supply Dispenser Cup	
7	C000052	Supply Dispenser Cup	
8	C000107	Dispenser Assembly	5 compartment

N/A = Part no longer available

Door Assembly - Models through 2/9/09 (Drawing 1 of 2) Models CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, CPC60H, CPC60M,

Models CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, CPC60H, CPC60M, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHQ1 and JP060PMQ1




Door Assembly - Models through 2/9/09 (Drawing 1 of 2)

C000559 Bolt 8 required for door hinge block to shell from 2 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to hinge 1 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to shell from 3 required for door hinge block to hinge 1 required for door hinge 2 required for door hinge 1 required for door h	
803017 Nut 2 required for door hinge block to hinge	ont
	Ont
C000561 Bolt 5 required for door hinge to door; 4 required handle hinge to door for models through required for door handle hinge to door for 3/23/04	3/23/04; 3
C000560 Nut 5 required for door hinge to door; 4 required handle hinge to door	red for door
F8549401 Nut 8 required for door glass retainer to door	
C000601 Stud 8 required for door glass retainer to door	
F431024 Nut 1 required for door handle to door handle	hinge
C001236 Nut 1 required for door handle to door handle	bushing
C001546 Door Bumper 2 required; Models starting 3/23/04	
C001032 Screw 2 required for door bumper; Models starti	ing 3/23/04
1 C003285 Door Gasket	
2 F8513501 Shell Front Gasket Kit	
3 F8549301 Bolt	
4 C000176 Door Hinge Bushing	
5 C000175 Hinge Block	
6 C000177 Washer	
7 C000604 Door Hinge	
8 C000190 Door Glass Gasket	
9 C000603 Door Glass Retainer	
10 C000191 Door Glass	
11 C001679P Door Handle	
12 C002726 Door Assembly	
13 C000181 Door Handle Bushing	
14 C000192 Door Handle Spring Bushing	
15 C001786 Door Handle Torsion Spring	
16 C001785 Bolt	
17 C000470 Door Handle Hinge Weldment	
18 C000180 Bolt	
19 C000077 Door Assembly Includes items 1-18	

Door Assembly - Models through 2/9/09 (Drawing 2 of 2)

Models CP040PHN1, CP040PHQ1, CP040PMN1, CP040PMQ1, CPC40H, CPC40M, IP040PHN1, IP040PHQ1, IP040PHN1, IP040PHQ1, IP040PHN1, IP040PHQ1, IP040PHQ1




PHM2775P_C002874

Door Assembly - Models through 2/9/09 (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000559	Bolt	8 required for door hinge block to shell front
	C000574	Nut	8 required for door hinge block to shell front
	803017	Nut	2 required for door hinge block to hinge
	C000561	Bolt	5 required for door hinge to door; 4 required for door handle hinge to door for models through 3/23/04; 3 required for door handle hinge to door for models starting 3/23/04
	C000560	Nut	5 required for door hinge to door; 4 required for door handle hinge to door
	F8549401	Nut	8 required for door glass retainer to door
	C000601	Stud	8 required for door glass retainer to door
	F431024	Nut	1 required for door handle to door handle hinge
	C001236	Nut	1 required for door handle to door handle bushing
	C001546	Door Bumper	2 required; Models starting 3/23/04
	C001032	Screw	2 required for door bumper; Models starting 3/23/04
1	C000177	Washer	
2	C000176	Door Hinge Bushing	
3	C000175	Hinge Block	
4	F8549301	Bolt	
5	C000521P	Door Gasket	
6	C000522	Door Glass Gasket	
7	C000520P	Door Glass	
8	C000523	Door	
9	C000519	Door Glass Retainer	
10	C000681	Door Hinge	
11	C000181	Door Handle Bushing	
12	C000180	Bolt	
13	C001679P	Door Handle	
14	C000470	Door Handle Hinge Weldment	
15	C001786	Door Handle Torsion Spring	
16	C001785	Bolt	
17	C000192	Door Handle Spring Bushing	
18	C000524	Door Assembly	Models starting 3/23/04; Includes items 1-17

Door Assembly - Models starting 2/10/09 (Drawing 1 of 2)

Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMX2, IP060PMX2, IP060PMX2, IP060PMX2, IP060PMQ1, IP060PMQ1,




Door Assembly - Models starting 2/10/09 (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000559	Bolt	8 required for door hinge block to shell front
	C000574	Nut	8 required for door hinge block to shell front
	803017	Nut	2 required for door hinge block to hinge
	C000561	Bolt	5 required for door hinge to door; 3 required for door handle hinge to door
	C000560	Nut	5 required for door hinge to door; 4 required for door handle hinge to door
	F8549401	Nut	8 required for door glass retainer to door
	C000601	Stud	8 required for door glass retainer to door
	F431024	Nut	1 required for door handle to door handle hinge
	C001236	Nut	1 required for door handle to door handle bushing
	C001546	Door Bumper	2 required; Models starting 3/23/04
	C001032	Screw	2 required for door bumper; Models starting 3/23/04
1	C003285	Door Gasket	
2	F8513501	Shell Front Gasket Kit	
3	F8549301	Bolt	
4	C000176	Door Hinge Bushing	
5	C000175	Hinge Block	
6	C000177	Washer	
7	C000604	Door Hinge	
8	C000190	Door Glass Gasket	
9	C000603	Door Glass Retainer	
10	C000191	Door Glass	
11	C001679P	Door Handle	
12	C002726	Door Assembly	
13	C000181	Door Handle Bushing	
14	C000192	Door Handle Spring Bushing	
15	C001786	Door Handle Torsion Spring	
16	C001785	Bolt	
17	C000470	Door Handle Hinge Weldment	
18	F431223	Pop Rivet	
19	F8390801	Magnet	
20	C002994	Door Magnet Mounting Bracket	
21	C000180	Bolt	
22	C000077	Door Assembly	Includes items 1-21

Door Assembly - Models starting 2/10/09 (Drawing 2 of 2)

Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM3092P_C002874

Door Assembly - Models starting 2/10/09 (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000559	Bolt	8 required for door hinge block to shell front
	C000574	Nut	8 required for door hinge block to shell front
	803017	Nut	2 required for door hinge block to hinge
	C000561	Bolt	5 required for door hinge to door; 3 required for door handle hinge to door
	C000560	Nut	5 required for door hinge to door; 4 required for door handle hinge to door
	F8549401	Nut	8 required for door glass retainer to door
	C000601	Stud	8 required for door glass retainer to door
	F431024	Nut	1 required for door handle to door handle hinge
	C001236	Nut	1 required for door handle to door handle bushing
	C001546	Door Bumper	2 required; Models starting 3/23/04
	C001032	Screw	2 required for door bumper; Models starting 3/23/04
1	C000177	Washer	
2	C000176	Door Hinge Bushing	
3	C000175	Hinge Block	
4	F8549301	Bolt	
5	C000521P	Door Gasket	
6	C000522	Door Glass Gasket	
7	C000520P	Door Glass	
8	C000523	Door	
9	C000519	Door Glass Retainer	
10	C000681	Door Hinge	
11	C000181	Door Handle Bushing	
12	C000180	Bolt	
13	C001679P	Door Handle	
14	C000470	Door Handle Hinge Weldment	
15	C001786	Door Handle Torsion Spring	
16	C000192	Door Handle Spring Bushing	
17	C001785	Bolt	
18	F431223	Pop Rivet	
19	F8390801	Magnet	
20	C002994	Door Magnet Mounting Bracket	
21	C000524	Door Assembly	Includes items 1-20

Door Lock AssemblyModels Through Serial No. 0902007001




Door Lock Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	81398	Screw	4 required for door lock cover to solenoid bracket; Models starting 3/23/04
	C000613	Screw	2 required for door solenoid bracket to door lock plate; Models through 3/23/04
	C000614	Screw	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracket
	C000578	Nut	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracket
	C000561	Bolt	4 required for door lock to shell front
	C000574	Nut	4 required for door lock to shell front
	C000567	Screw	2 required for door latch to door lock plate
	C000571	Washer	2 required for door latch to door lock plate; Models starting 3/23/04
	C000572	Screw	2 required for door lock solenoid to bracket
	C000612	Screw	3 required for door lock catch to door lock plate
	C000430	Bolt	4 required for door solenoid bracket to door lock plate for models starting 3/23/04; 4 required for door lock cover to door lock plate for models through 3/23/04
	C000576	Nut	2 required for door lock cover to door lock plate
	C000867P	Door Lock Harness	
	C003291	Jump Wire	
1	C000688	Door Lock Cover	
2	C000431	Spring	
3	C000430	Bolt	
4	C000278	Door Lock Microswitch	
5	C000684	Door Lock Plate	
6	F8654101	Door Lock Solenoid	
7	C000185	Door Lock Catch	
8	C000276	Door Lock Slide Spring	
9	C000271	Door Lock Switch Slide	
10	N/A	Door Latch	Models through 3/23/04
	C001244	Door Latch	Models starting 3/23/04
11	C000687	Door Lock Spring Cover	
12	C003022	Door Lock Solenoid Bracket	
13	C002996M	Door Lock Kit	
	N/A	Door Lock Assembly	Includes items 1-12; Models through 7/14/11 with C001036P Door Lock Assembly MUST order C002996M Door Lock Kit

N/A = Part no longer available

Door Lock Assembly with Magnetic Sensor Models Starting Serial No. 0902007002




PHM3149P_C002874

Door Lock Assembly with Magnetic Sensor


REF	PART NO.	DESCRIPTION	COMMENTS
	81398	Screw	4 required for door lock cover to solenoid bracket; Models starting 3/23/04
	C000613	Screw	2 required for door solenoid bracket to door lock plate; Models through 3/23/04
	C000614	Screw	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracket
	C000578	Nut	2 required for door lock switch to door lock plate; 2 required for door lock switch to door lock solenoid bracket
	C000561	Bolt	4 required for door lock to shell front
	C000574	Nut	4 required for door lock to shell front
	C000567	Screw	2 required for door latch to door lock plate
	C000571	Washer	2 required for door latch to door lock plate; Models starting 3/23/04
	C000572	Screw	2 required for door lock solenoid to bracket
	C000612	Screw	3 required for door lock catch to door lock plate
	C000430	Bolt	4 required for door solenoid bracket to door lock plate for models starting 3/23/04; 4 required for door lock cover to door lock plate for models through 3/23/04
	C000576	Nut	2 required for door lock cover to door lock plate
	C000867P	Door Lock Harness	
	C003291	Jump Wire	
1	C000688	Door Lock Cover	
2	C000431	Spring	
3	C000278	Door Lock Microswitch	
4	C000430	Bolt	
5	C002995	Magnetic Door Switch Bracket	
6	C003000	Reed Switch Assembly	
7	C000684	Door Lock Plate	
8	J1111905	Blind Rivet	
9	F8654101	Door Lock Solenoid	
10	C000271	Door Lock Switch Slide	
11	C000276	Door Lock Slide Spring	
12	C000185	Door Lock Catch	
13	N/A	Door Latch	Models through 3/23/04
	C001244	Door Latch	Models starting 3/23/04
14	C000687	Door Lock Spring Cover	
15	C003022	Door Lock Solenoid Bracket	
16	B12351001	Door Lock Spring	Models starting 12/13/10 through 5/12/11
17	F431215	Pop Rivet	Models starting 12/13/10 through 5/12/11
18	C002996M	Door Lock Kit	Includes items 1-17

N/A = Part no longer available




PHM2736P_C002874

REF	PART NO.	DESCRIPTION	COMMENTS
	C002610P	Inlet Valve Harness	
	C000567	Screw	2 required for hot manifold to valve panel; 4 required for vacuum breaker to valve panel
	F431024	Nut	2 required for drain valve to drain valve mounting bracket; 2 required for hot manifold to valve panel
	F430935	Screw	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Hot water valve to vacuum breaker
	F8514701	Coil	Use with F8322909 Steam Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322909 Steam Valve
	F8379504	Valve Rebuild Kit	Use with F8322909 Steam Valve
1	C001366	Flange and Nipple Assembly	
2	F420403	Tee	
3	F420502	Street Elbow	
4	F420107	Nipple	
5	F380991P	Water Valve Repair Kit	3/4 inch; Use with F381700P Valve
	F8322909P	Valve	Replaces F381700P Valve; Includes F8322909 Steam Valve and F8514701 Coil
6	F380986P	DIN Coil	120 Volt
	F380987P	DIN Coil	240 Volt
7	F421951	Hose Barb	Brass
8	C000436P	Water Valve	
	G582P3	Diaphragm and Guide Kit	
9	C000424	Adapter	
10	C000420	Coupling	
11	C000426	Hot Plumbing Assembly	5 cup; Includes items 1-9




PHM2737P_C002874

C002608P Inlet Valve Harness C000567 Screw 2 required for hot manifold to valve panel; 4 required for hot manifold to valve panel; 2 required required for drain valve mounting bracket F430935 Screw 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04 C000571 Washer 4 required for drain valve to drain valve mounting	uired for
F431024 Nut 2 required for hot manifold to valve panel; 2 required for hot manifold to valve panel; 2 required for hot manifold to valve panel; 2 required for drain valve mounting bracket F430935 Screw 2 required for drain valve to drain valve mounting bracket; Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04	uired for
F430935 Screw 2 required for drain valve to drain valve mounting bracket C000585 Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04	
C000585 Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04	n hracket
bracket; Models through 3/23/04	y Diacket
C000571 Washer A required for drain valve to drain valve mounting	9
bracket; Models starting 3/23/04	9
F200128P Water Hose Hot water valve to vacuum breaker	
F8514701 Coil Use with F8322909 Steam Valve	
F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve	
F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve	
1 C001664 Hot Plumbing Assembly Includes items 2-10	
2 C001366 Flange and Nipple Assembly	
3 F420502 Street Elbow	
4 F420107 Nipple	
5 F380991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve	
F8322909P Valve Replaces F381700P Valve; Includes F8322909 Valve and F8514701 Coil	Steam
6 F380986P DIN Coil 120 Volt	
F380987P DIN Coil 240 Volt	
7 F421951 Hose Barb Brass	
8 C000716P Valve 2-way	
G582P3 Diaphragm and Guide Kit	
9 C000424 Adapter	
10 C000420 Coupling	
11 F420403 Tee	



PHM2738P_C002874


C002611P Inlet Valve Harness C000567 Screw 2 required for cold manifold to valve panel; 4 require vacuum breaker to valve panel F431024 Nut 2 required for drain valve to drain valve mounting bracket; 2 required for cold manifold to valve panel F430935 Screw 2 required for drain valve to drain valve mounting bracket; 2 required for drain valve mounting bracket; Models through 3/23/04 C000585 Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04 C000571 Washer 4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04 F200128P Water Hose Cold water valve to vacuum breaker F8514701 Coil Use with F8322909 Steam Valve F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized 5 F380991P Water Valve Repair Kit 3/4 inch; Use with F381700P Valve	
required for drain valve to drain valve mounting bracket; 2 required for drain valve to drain valve mounting bracket; 2 required for drain valve to drain valve mounting bracket; 2 required for drain valve to drain valve mounting bracket; Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04 C000571	
bracket; 2 required for cold manifold to valve panel F430935 Screw 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04 C000585 Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04 C000571 Washer 4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04 F200128P Water Hose Cold water valve to vacuum breaker F8514701 Coil Use with F8322909 Steam Valve F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	d for
C000585 Washer 2 required for drain valve to drain valve mounting bracket; Models through 3/23/04 C000571 Washer 4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04 F200128P Water Hose Cold water valve to vacuum breaker F8514701 Coil Use with F8322909 Steam Valve F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
bracket; Models through 3/23/04 C000571 Washer 4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04 F200128P Water Hose Cold water valve to vacuum breaker F8514701 Coil Use with F8322909 Steam Valve F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	icket
Bracket; Models starting 3/23/04	
F8514701 Coil Use with F8322909 Steam Valve F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
F8382301 DIN Valve Adapter Kit Use with F8322909 Steam Valve F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
F8379504 Valve Rebuild Kit Use with F8322909 Steam Valve 1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
1 C000425 Cold Plumbing Assembly Includes items 2-9 2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
2 C001366 Flange and Nipple Assembly 3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
3 F420107 Nipple Galvanized 4 F420502 Street Elbow Galvanized	
4 F420502 Street Elbow Galvanized	
5 F380991P Water Valve Repair Kit 3/4 inch: Use with F381700P Valve	
Trace vary repair at	
F8322909P Valve Replaces F381700P Valve: Includes F8322909 Stea Valve and F8514701 Coil	m
6 F380986P DIN Coil 120 Volt	
F380987P DIN Coil 240 Volt	
7 F421951 Hose Barb Brass	
8 C000436P Water Valve 3-way	
G582P3 Diaphragm and Guide Kit	
9 C000424 Adapter	
10 F420403 Tee Galvanized	



PHM2739P_C002874

REF	PART NO.	DESCRIPTION	COMMENTS
	C002608P	Inlet Valve Harness	
	C000567	Screw	2 required for cold manifold to valve panel; 4 required for vacuum breaker to valve panel
	F431024	Nut	2 required for drain valve to drain valve mounting bracket; 2 required for cold manifold to valve panel
	F430935	Screw	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Cold water valve to vacuum breaker
	F8514701	Coil	Use with F8322909 Steam Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322909 Steam Valve
	F8379504	Valve Rebuild Kit	Use with F8322909 Steam Valve
1	C001106	Cold Plumbing Assembly	Includes items 2-5
2	C001366	Flange and Nipple Assembly	
3	F380991P	Water Valve Repair Kit	3/4 inch; Use with F381700P Valve
	F8322909P	Valve	Replaces F381700P Valve: Includes F8322909 Steam Valve and F8514701 Coil
4	F380986P	DIN Coil	120 Volt
	F380987P	DIN Coil	240 Volt
5	F421951	Hose Barb	
6	F420502	Street Elbow	Galvanized

Auxiliary Plumbing Assembly





PHM2740P_C002874

Auxiliary Plumbing Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	4 required for vacuum breaker to valve panel
	F430935	Screw	2 required for drain valve to drain valve mounting bracket
	F431024	Nut	2 required for drain valve to drain valve mounting bracket
	C000585	Washer	2 required for drain valve to drain valve mounting bracket; Models through 3/23/04
	C000571	Washer	4 required for drain valve to drain valve mounting bracket; Models starting 3/23/04
	F200128P	Water Hose	Auxiliary fill water valve to vacuum breaker
	F8514701	Coil	Use with F8322909 Steam Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322909 Steam Valve
	F8379504	Valve Rebuild Kit	Use with F8322909 Steam Valve
	F380986P	DIN Coil	120 Volt; Parker
1	C001187	Auxiliary Plumbing Assembly	Includes items 2-4
2	C001366	Flange and Nipple Assembly	
3	F380991P	Water Valve Repair Kit	3/4 inch; Use with F381700P Valve
	F8322909P	Valve	Replaces F381700P Valve: Includes F8322909 Steam Valve and F8514701 Coil
4	F421951	Hose Barb	

Supply Hose and Filter (Optional)






B091P_C002874

Supply Hose and Filter (Optional)

REF	PART NO.	DESCRIPTION	COMMENTS
1	F270306P	Filter	Standard thread
	F270305	Filter	Metric thread
2	803615	Washer	Filter
3	F270406	Replacement Filter	.11 mm
	F270405	Replacement Filter	.25 mm
4	F270407	Filter Housing Cap Gasket	
5	803615	Washer	Filter
6	F200116	Water Hose	3/8 inch; Standard thread
	F200164	Water Hose	3/4 inch; Standard thread
	F200165	Water Hose	3/8 inch; Metric thread
	F200166	Water Hose	3/4 inch; Metric thread

Steam Heat Assembly


Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH40M, IPH180, JP040PHN1 and JP040PHQ1



Steam Heat Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F8514701	Coil	Use with F8322802 Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322802 Valve
	F8379501P	Valve Kit	Use with F8322802 Valve
	F380986P	DIN Coil	120 Volt; Parker
1	C000775	Steam Hose	
2	C001003	Steam Hose Insulation	
3	C002748P	Steam Cord Assembly	
4	F8322802	Valve	Replaces F380786P Steam Valve; Includes F8514701 Coil; For models that have been upgraded with F8521601 DIN Valve Kit
	F8521601	DIN Valve Kit	Replaces F380786P Steam Valve; Includes F8322802 Valve and F8514701 Coil
5	C000981	Steam Valve Mounting Bracket	
6	C000999	Nipple	
7	C000733	Steam Valve Mounting Flange	
8	F8368201	Steam Injector Tube Assembly	
9	F421703	Street Elbow	
10	C001009	Steam Option Assembly	Includes items 1-8


Steam Option Assembly
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1



Steam Option Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	F8514701	Coil	Use with F8322802 Valve
	F8382301	DIN Valve Adapter Kit	Use with F8322802 Valve
	F8379501P	Valve Kit	Use with F8322802 Valve
	F380986P	DIN Coil	120 Volt; Parker
1	C001002	Steam Option Assembly	Includes items 2-9
2	F421703	Street Elbow	
3	F83638201	Steam Injector Tube Assembly	
4	C000736	Steam Hose	
5	C001003	Steam Hose Insulation	
6	C002748P	Steam Cord Assembly	
7	F8322802	Valve	Replaces F380786P Steam Valve; Includes F8514701 Coil; For models that have been upgraded with F8521601 DIN Valve Kit
	F8521601	DIN Valve Kit	Replaces F380786P Steam Valve; Includes F8322802 Valve and F8514701 Coil
8	C000981	Steam Valve Mounting Bracket	
9	C000999	Nipple	
10	C000733	Steam Valve Mounting Flange	

Shell Assembly (Drawing 1 of 2)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1




PHM2785P_C002874

Shell Assembly (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 1/10/10
	70391101	Screw	8 required for shell back to frame; Models starting 1/11/10
	C000599	Vacuum Breaker Hose	Air trap to water level switch; Models starting 3/23/04
1	C002975	Shell Front Assembly	
2	C001735	Shell Band and Clamp Weldment	
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001762	Shell Front Gasket	Models starting 3/23/04
4	C000518	Shell Assembly	

Shell Assembly (Drawing 2 of 2)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1



PHM2786P_C002874


Shell Assembly (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 3/23/04
	C001032	Screw	8 required for shell back to frame; Models starting 3/23/04
	C000599	Vacuum Breaker Hose	Air trap to water level switch; Models starting 3/23/04
1	C002976P	Shell Front Assembly	
2	N/A	Shell Band Assembly	Models through 3/23/04
	F601216	Shell Gasket Shield	Models through 3/23/04
	C000659	Shell Band and Clamp Weldment	Models starting 3/23/04
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001763P	Shell Front Gasket	Models starting 3/23/04
4	C000093	Shell Support	

N/A = Part no longer available

Electric Heat Shell Assembly (Drawing 1 of 2) Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H,


Models CP040PHN1, CP040PHQ1, CP040PHX2, CP040PMN1, CP040PMQ1, CP040PMX2, CPC40H, CPC40M, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40H, IPH40H, IPH40M, IPH180, JP040PHN1 and JP040PHQ1



Electric Heat Shell Assembly (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 3/23/04
	C001032	Screw	8 required for shell back to frame; Models starting 3/23/04
	C002755	Electric Heat Harness	
	C002756	Electric Heat Harness	
	C002724	Electric Heat Harness	Option 1
	C002830	Electric Heat Harness	Option 2
	C002758	Electric Heat Harness	200-240 Volt
1	C002975	Shell Front Assembly	
2	C001735	Shell Band and Clamp Weldment	
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001762	Shell Front Gasket	Models starting 3/23/04
4	C000949	Electric Heat Shell Assembly	
5	209/00562/30	Heating Element	


Electric Heat Shell Assembly (Drawing 2 of 2)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CP060PMN1, CP060PMQ1, CP060PMX2, CPC60H, CPC60M, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60H, IPH60M, IPH270, JP060PHN1, JP060PHN2, JP060PHQ1 and JP060PMQ1



Electric Heat Shell Assembly (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	C001232	Air Trap Tube	Models through 3/23/04
	C001856	Screw	2 required; To hold shell band together
	F431024	Nut	2 required; To hold shell band together
	C000590	Washer	4 required for models through 3/23/04; As required for models starting 3/23/04; To hold shell band together
	C000273	Bolt	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000611	Nut	4 required for shell support bracket to frame; 2 required for shell support bracket to shell
	C000583	Washer	8 required for shell support bracket to frame; 4 required for shell support bracket to shell
	C000561	Bolt	8 required for shell back to frame; Models through 3/23/04
	C001032	Screw	8 required for shell back to frame; Models starting 3/23/04
1	C002976P	Shell Front Assembly	
2	N/A	Shell Band Assembly	Models through 3/23/04
	F601216	Shell Gasket Shield	Models through 3/23/04
	C000659	Shell Band and Clamp Weldment	Models starting 3/23/04
3	N/A	Shell Front Gasket	Models through 3/23/04
	C001763P	Shell Front Gasket	Models starting 3/23/04
4	C000950	Electric Heat Shell Assembly	
5	209/00562/30	Heating Element	

Drive Box Assembly




PHM2747P_C002874

Drive Box Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000866	Rear Enclosure Harness	
	C000567	Screw	4 required for drive box to valve panel
	C000571	Washer	4 required for drive box to valve panel
	F430909	Screw	2 required for exhaust bracket to box; 4 required for chemical terminal mounting bracket to box for models through 3/23/04; 3 required for chemical terminal mounting bracket to box for models starting 3/23/04; 4 required for AC drive to box; 4 required for EMI filter to box; 4 required for transformer to box; 2 required for ground lug to box
	F431133	Washer	4 required for AC drive to box
	C000575	Screw	2 required for input power block to box
	F430938	Screw	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
	C000568	Nut	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
	C002779	Chemical Supply Harness	PT1
	C002780	Chemical Supply Harness	PT2
	C002781	Chemical Supply Harness	PT3
	C003020	Electric Heat Control Harness	
	F140602	Tie Wrap Mounting Clamp	
1	N/A	Circuit Breaker	Design 1 models; 1 Amp; 380-480 Volt; Order C0977P3 Circuit Breaker Kit
	N/A	Circuit Breaker	Design 1 models; 2 Amp; 200-240 Volt; Order C0978P3 Circuit Breaker Kit
	C0977P3	Circuit Breaker Kit	380-480 Volt; Includes F350217 Circuit Breaker
	C0978P3	Circuit Breaker Kit	200-240 Volt; Includes C003135 Circuit Breaker
	F350217	Circuit Breaker	Design 2 models or models that have been retrofitted with C0977P3 Circuit Breaker Kit; .5 Amp; 380-480 Volt
	C003135P	Circuit Breaker	Design 2 models or models that have been retrofitted with C0978P3 Circuit Breaker Kit; 1 Amp; 200-240 Volt
2	C000370	Power Block Terminal	12 pole; Chemical supply
3	C000373	Mounting Bracket	
4	C000203	Transformer	150VA
5	C000318	Thermostat	
6	C000323	Exhaust Bracket	
7	C001050	Drive Box Assembly	
8	C000290	Power Block Terminal	Non-electric heat models only
9	N/A	Ground Terminal	

Electric Heat Drive Box Assembly




PHM2748P_C002874

Electric Heat Drive Box Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	C000567	Screw	4 required for drive box to valve panel
	C000571	Washer	4 required for drive box to valve panel
	F430909	Screw	2 required for exhaust bracket to box; 4 required for chemical terminal mounting bracket to box for models through 3/23/04; 3 required for chemical terminal mounting bracket to box for models starting 3/23/04; 4 required for AC drive to box; 4 required for EMI filter to box; 4 required for transformer to box; 2 required for ground lug to box
	F431133	Washer	4 required for AC drive to box
	C000575	Screw	2 required for input power block to box
	F430938	Screw	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
	C000568	Nut	4 required for cooling fan to valve panel; 2 required for chemical signal terminal block to bracket
1	C000308P	Contactor	400 Volt; 50 Amp
	C000309P	Contactor	200 Volt; 85 Amp
2	N/A	Circuit Breaker	Design 1 models; 1 Amp; 380-480 Volt; Order C0977P3 Circuit Breaker Kit
	N/A	Circuit Breaker	Design 1 models; 2 Amp; 200-240 Volt; Order C0978P3 Circuit Breaker Kit
	C0977P3	Circuit Breaker Kit	380-480 Volt; Includes F350217 Circuit Breaker
	C0978P3	Circuit Breaker Kit	200-240 Volt; Includes C003135 Circuit Breaker
	F350217	Circuit Breaker	Design 2 models or models that have been retrofitted with C0977P3 Circuit Breaker Kit
	C003135P	Circuit Breaker	Design 2 models or models that have been retrofitted with C0978P3 Circuit Breaker Kit
3	C000370	Power Block Terminal	Chemical supply
4	C000373	Mounting Bracket	
5	C000203	Transformer	
6	C000318	Thermostat	
7	C000323	Exhaust Bracket	
8	C001050	Drive Box Assembly	
9	M413865	Power Distribution Block	
10	N/A	Ground Lug Terminal	
11	C001194	Fuse	15 Amp; Models CP060PHN1, CP060PHQ1, CP060PMN1, CP060PMQ1, CPC60H, CPC60M, IP060PHN1, IP060PHQ1, IP060PMN1, IP060PMQ1, IPH60H, IPH60M and IPH270
	C001196	Fuse	10 Amp; All other models
12	C001197	Fuse Holder	

AC Drive and EMI Filter




PHM2747PA_C002874

AC Drive and EMI Filter

REF	PART NO.	DESCRIPTION	COMMENTS
1	C000287	Inverter	200-240 Volt; 2 hp; Models CP040PHQ1, CP040PMQ1, CP060PMQ1, CPC40H, CPC40M, CPC60M, IP040PHQ1, IP040PMQ1, IP060PMQ1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	N/A	Inverter	200-240 Volt; 3 hp; Models CP060PHQ1, CPC60H, IP060PHQ1, IPH60H and JP060PHQ1; Order C003043 160-series to PowerFlex 40 Drive Kit
	C000288	Inverter	380-480 Volt; 2 hp; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180, IPH270 and JP040PHN1; Order C003033 160-series to PowerFlex 40 Drive Kit
	N/A	Inverter	380-480 Volt; 3 hp; Models CP060PHN1, CPC60H, IP060PHN1 and IPH60H; Order C003045 160-series to PowerFlex 40 Drive Kit
2	F330281	EMI Filter	380-480 Volt; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	F330280P	EMI Filter	200-240 Volt models CP040PMQ1, CP060PHQ1, CP060PMQ1, CPC40H, CPC40M, CPC60H, CPC60M, IP040PHQ1, IP040PMQ1, IP060PHQ1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270; 400 Volt models CP060PHN1, CPC60H, IP060PHN1 and IPH60H

AC Drive and EMI Filter - Electric Heat Models




PHM2748PA_C002874

AC Drive and EMI Filter - Electric Heat Models

REF	PART NO.	DESCRIPTION	COMMENTS
1	C000287	Inverter	200-240 Volt; 2 hp; Models CP040PHQ1, CP040PMQ1, CP060PMQ1, CPC40H, CPC40M, CPC60M, IP040PHQ1, IP040PMQ1, IP060PMQ1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	N/A	Inverter	200-240 Volt; 3 hp; Models CP060PHQ1, CPC60H, IP060PHQ1, IPH60H and JP060PHQ1; Order C003043 160-series to PowerFlex 40 Drive Kit
	C000288	Inverter	380-480 Volt; 2 hp; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270; Order C003033 160-series to PowerFlex 40 Drive Kit
	N/A	Inverter	380-480 Volt; 3 hp; Models CP060PHN1, CPC60H, IP060PHN1 and IPH60H; Order C003045 160-series to PowerFlex 40 Drive Kit
2	F330281	EMI Filter	380-480 Volt; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	F330280P	EMI Filter	200-240 Volt models CP040PMQ1, CP060PHQ1, CP060PMQ1, CPC40H, CPC40M, CPC60H, CPC60M, IP040PHQ1, IP040PMQ1, IP060PHQ1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270; 400 Volt models CP060PHN1, CPC60H, IP060PHN1 and IPH60H

PowerFlex Drive and EMI Filter - Design 1 Models




PHM3028P_C002874

PowerFlex Drive and EMI Filter - Design 1 Models

REF	PART NO.	DESCRIPTION	COMMENTS
	C003028	Harness	
1	C003031	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP040, CPC40, IP040 and IPH40 M-series models; Models with LM26252 Lincoln Motor; Includes F8168603 AC Drive
	C003039	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP060, CPC60, IP060, IPH60 and JP060 M-series models; Includes F8168603 AC Drive
	C003033	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP040, CPC40, IP040 and IPH40 M-series models; Models with LM26252 Lincoln Motor; Includes F8168604 AC Drive
	C003041	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP060, CPC60, IP060, IPH60 and JP060 M-series models; Includes F8168604 AC Drive
	C003035	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP040, CPC40, IP040, IPH40 and JP040 H-series models; Includes F8168603 AC Drive
	C003043	160-Series to PowerFlex 40 Drive Kit	200-240 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models; Includes F8168603 AC Drive
	C003046	PowerFlex 40 Drive	380-480 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models that have been retrofitted with C003045 160-series to PowerFlex 40 Drive Kit; Includes F8168604 AC Drive
	C003044	PowerFlex 40 Drive	200-240 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models that have been retrofitted with C003043 160-series to PowerFlex 40 Drive Kit; Includes F8168603 AC Drive
	C003037	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP040, CPC40, IP040, IPH40 and JP040 H-series models; Includes F8168604 AC Drive
	C003045	160-Series to PowerFlex 40 Drive Kit	380-480 Volt; CP060, CPC60, IP060, IPH60 and JP060 H-series models; Includes F8168604 AC Drive
2	F8053902	EMI Filter	380-480 Volt; Models CP040PHN1, CP040PMN1, CP060PMN1, CPC40H, CPC40M, CPC60M, IP040PHN1, IP040PMN1, IP060PMN1, IPH40H, IPH40M, IPH60M, IPH180 and IPH270
	F8053901P	EMI Filter	200-240 Volt models CP040PMQ1, CP060PHQ1, CP060PMQ1, CPC40H, CPC40M, CPC60H, CPC60M, IP040PHQ1, IP040PMQ1, IP060PHQ1, IP060PMQ1, IPH40H, IPH40M, IPH60H, IPH60M, IPH180 and IPH270; 400 Volt models CP060PHN1, CPC60H, IP060PHN1 and IPH60H

PowerFlex Drive and EMI Filter - Design 2 Models

Models CP040PHX2, CP040PMX2, CP060PHN2, CP060PHQ2, CP060PHX2, CP060PMX2, IP040PHN2, IP040PHX2, IP040PMX2, IP060PHN2, IP060PHX2, IP060PHX2, IP060PHX2, IP060PMX2 and JP060PHN2




PHM3028P_C002874

PowerFlex Drive and EMI Filter - Design 2 Models

REF	PART NO.	DESCRIPTION	COMMENTS
1	C003044	PowerFlex 40 Drive	200-240 Volt; Models CP060PHQ2, CP060PHX2, IP060PHN2, IP060PHQ2, IP060PHX2 and JP060PHN2; Includes F8168603 AC Drive
	C003046	PowerFlex 40 Drive	380-480 Volt; Models CP060PHN2, IP060PHN2 and JP060PHN2; Includes F8168604 AC Drive
	C003032	PowerFlex 40 Drive	200-240 Volt; Models CP040PMX2 and IP040PMX2; Includes F8168603 AC Drive
	C003034	PowerFlex 40 Drive	380-480 Volt; Models CP040PMX2 and IP040PMX2; Includes F8168604 AC Drive
	C003036	PowerFlex 40 Drive	200-240 Volt; Models CP040PHX2 and IP040PHX2; Includes F8168603 AC Drive
	C003038	PowerFlex 40 Drive	380-480 Volt; Models CP040PHX2, IP040PHN2 and IP040PHX2; Includes F8168604 AC Drive
	C003040	PowerFlex 40 Drive	200-240 Volt; Models CP060PMX2, IP060PMN2 and IP060PMX2; Includes F8168603 AC Drive
	C003042	PowerFlex 40 Drive	380-480 Volt; Models CP060PMX2, IP060PMN2 and IP060PMX2; Includes F8168604 AC Drive
2	F8053902	EMI Filter	Models CP040PHX2, CP040PMX2, IP040PHX2 and IP040PMX2
	F8053901P	EMI Filter	Models CP060PHN2, CP060PHQ2, CP060PHX2, IP060PHN2, IP060PHQ2 and JP060PHN2

Main Assembly (Drawing 1 of 8)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CPC60H, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IPH60H, JP060PHN1, JP060PHN2 and JP060PHQ1




PHM2796P_C002874

Main Assembly (Drawing 1 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000680	Adapter	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000583	Washer	4 required for shell support bracket to shell
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker
	F200201	Hose Clamp	2 required for fill inlet hose
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04
	C000273	Bolt	2 required for shell support bracket to shell
	C000611	Nut	2 required for shell support bracket to shell
	C000567	Screw	4 required for vacuum breaker to valve panel
	F431024	Nut	4 required for vacuum breaker to valve panel; Models through 3/23/04
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04
1	C000379	Supply Dispenser Hose	
2	C002054	Shell Support Brace	Models starting 3/23/04
3	C000079	Lower Shell Support Bracket	
4	225/10004/00	Thermostat Grommet	
5	C002636	Temperature Probe Assembly	
6	N/A	Frame Weldment	
7	C000378	Water Inlet Hose	
8	C000210	Fan Filter Guard Assembly	
	F200318900P	Filter	5 pack
9	C000390	Vacuum Breaker Assembly	
10	N/A	Grease Fitting	2 required; Models through 3/23/04
	C000549	Grease Fitting	2 required; Models starting 3/23/04
11	N/A	Grease Coupling	2 required; Models through 3/23/04
	C001789	Connector	2 required; Models starting 3/23/04
12	C000211	Fan	
13	C000317	Circuit Breaker	2 Amp

Main Assembly (Drawing 2 of 8)
Models CP060PHN1, CP060PHN2, CP060PHQ1, CP060PHQ2, CP060PHX1, CP060PHX2, CPC60H, IP060PHN1, IP060PHN2, IP060PHQ1, IP060PHQ2, IP060PHX2, IPH60H, JP060PHN1, JP060PHN2 and JP060PHQ1




PHM3226P_C002874

Main Assembly (Drawing 2 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000971	Overflow T-Drain Assembly	
	C002422	Motor Cable	
	C000304	Motor Cable	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	C002858	Dual Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003316P	Alignment Tool	
1	C000223P	Cylinder Bushing	
2	C002637P	Proximity Switch Assembly	
3	C000222	Cylinder Pulley	
4	C000599	Vacuum Breaker Hose	
5	C000662	Air Trap Tube	Brass
6	C000654	Air Trap Tube Elbow	Rubber
7	C000224	Motor Pulley	
8	C001053	Belt	
9	F280233P	Bushing	
10	C000130	Motor Bracket	
11	C000205	Motor	
12	N/A	Belt Tension Spring	Models through 3/23/04
	C001800	Belt Tension Spring	Models starting 3/23/04
13	C000412	Water Reuse Hose	
14	C001793	Сар	Models starting 3/23/04
15	C003353	Drain Valve	2 required
16	F200201	Hose Clamp	2 required for drain hose
17	F200165100	Drain Hose	No. 56
18	C001649	Reducing Connector	2 required; Models starting 3/23/04 through 3/6/13
19	C000377	Overflow Hose	
20	C000411	Drain Hose	

Main Assembly (Drawing 3 of 8)
Models CP060PMN1, CP060PMQ1, CP060PMX2, CPC60M, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60M, IPH270 and JP060PMQ1




PHM2797P_C002874

Main Assembly (Drawing 3 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000680	Adapter	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C001772	Vacuum Breaker Cover	Models starting 3/23/04
	C000583	Washer	4 required for shell support bracket to shell
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker
	F200201	Hose Clamp	2 required for fill inlet hose
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04
	C000273	Bolt	2 required for shell support bracket to shell
	C000611	Nut	2 required for shell support bracket to shell
	C000567	Screw	4 required for vacuum breaker to valve panel
	C002617P	Single Fan Harness	
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04
	F431024	Nut	4 required for vacuum breaker to valve panel; Models through 3/23/04
1	C000390	Vacuum Breaker Assembly	
2	N/A	Grease Fitting	2 required; Models through 3/23/04
	C000549	Grease Fitting	2 required; Models starting 3/23/04
3	N/A	Grease Coupling	2 required; Models through 3/23/04
	C001789	Connector	2 required; Models starting 3/23/04
4	C000211	Fan	
5	C000317	Circuit Breaker	2 Amp
6	C000210	Fan Filter Guard Assembly	
	F200318900P	Filter	5 pack
7	C000379	Supply Dispenser Hose	
8	C000079	Lower Shell Support Bracket	
9	C002636	Temperature Probe Assembly	
10	225/10004/00	Thermostat Grommet	
11	C002054	Shell Support Brace	Models starting 3/23/04
12	C000780	Frame Assembly	
13	C000378	Water Inlet Hose	


Main Assembly (Drawing 4 of 8)
Models CP060PMN1, CP060PMQ1, CP060PMX2, CPC60M, IP060PMN1, IP060PMN2, IP060PMQ1, IP060PMX2, IPH60M, IPH270 and JP060PMQ1



Main Assembly (Drawing 4 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C002422	Motor Cable	
	C000304	Motor Cable	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	C002858	Dual Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003315P	Alignment Tool	
1	C000662	Air Trap Tube	Brass
2	C000654	Air Trap Tube Elbow	Rubber
3	C000791P	Motor Pulley	
4	C000130	Motor Bracket	
5	N/A	Belt Tension Spring	Models through 3/23/04
	C001790	Belt Tension Spring	Models starting 3/23/04
6	C000204	Motor	
7	F280233P	Bushing	
8	C000411	Drain Hose	
9	N/A	Belt	Models through 3/23/04
	C001264	Belt	Models starting 3/23/04
10	C003353	Drain Valve	
11	F200201	Hose Clamp	2 required for drain hose
12	F200165100	Drain Hose	No. 56
13	C001649	Reducing Connector	2 required; Models starting 3/23/04 through 3/6/13
14	C000377	Overflow Hose	
15	C000222	Cylinder Pulley	
16	C000599	Vacuum Breaker Hose	
17	C000746	Cylinder Bushing	
18	C002637P	Proximity Switch Assembly	

Main Assembly (Drawing 5 of 8)
Models CP040PMN1, CP040PMQ1, CP040PMX2, CPC40M, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40M, IPH180 and JP060PMQ1




PHM2795P_C002874

Main Assembly (Drawing 5 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000680	Adapter	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000583	Washer	4 required for shell support bracket to shell
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker
	F200201	Hose Clamp	2 required for fill inlet hose
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04
	C000273	Bolt	2 required for shell support bracket to shell
	C000611	Nut	2 required for shell support bracket to shell
	C000567	Screw	4 required for vacuum breaker to valve panel
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04
1	C000379	Supply Dispenser Hose	
2	C000516	Lower Shell Support Bracket	
3	225/10004/00	Thermostat Grommet	
4	C002636	Temperature Probe Assembly	
5	C002055	Shell Support Brace	
6	C000813	Frame Assembly	
7	C000677	Water Inlet Hose	
8	C000210	Fan Filter Guard Assembly	
	F200318900P	Filter	5 pack
9	N/A	Grease Fitting	2 required; Models through 3/23/04
	C000549	Grease Fitting	2 required; Models starting 3/23/04
10	N/A	Grease Coupling	2 required; Models through 3/23/04
	C001789	Connector	2 required; Models starting 3/23/04
11	C001772	Vacuum Breaker Cover	
12	C000390	Vacuum Breaker Assembly	
13	C000317	Circuit Breaker	2 Amp
14	C000211	Fan	

N/A = Part no longer available

Main Assembly (Drawing 6 of 8)
Models CP040PMN1, CP040PMQ1, CP040PMX2, CPC40M, IP040PMN1, IP040PMQ1, IP040PMX2, IPH40M, IPH180 and JP060PMQ1




PHM2948P_C002874

Main Assembly (Drawing 6 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000662	Air Trap Tube	Brass
	C002421	Motor Cable	
	C000304	Motor Cable	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003313P	Alignment Tool	
1	C000746	Cylinder Bushing	
2	C000599	Vacuum Breaker Hose	
3	C000654	Air Trap Tube Elbow	Rubber
4	C001053	Belt	
5	C001051P	Motor Pulley	
6	C000689	Motor Bracket	
7	C000994	Spring Clip	
8	N/A	Belt Tension Spring	Models through 3/23/04
	C001790	Belt Tension Spring	Models starting 3/23/04
9	C000204	Motor	
10	F280233P	Bushing	
11	C000411	Drain Hose	
12	C000222	Cylinder Pulley	
13	F200165100	Drain Hose	No. 56
14	F200201	Hose Clamp	2 required for drain hose
15	C003353	Drain Valve	
16	C000676	Overflow Hose	
17	C001649	Reducing Connector	2 required; Models through 3/6/13

Main Assembly (Drawing 7 of 8)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CPC40H, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IPH40H, JP040PHN1 and JP040PHQ1




PHM2794P_C002874

Main Assembly (Drawing 7 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C000679	Vacuum Breaker Plug	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000680	Adapter	6 required; Models through 3/23/04; Use with old style vacuum breaker
	C000583	Washer	4 required for shell support bracket to shell
	F200222	Hose Clamp	4 required for inlet valve to vacuum breaker
	F200201	Hose Clamp	2 required for fill inlet hose
	C000552	Hose	Flush hose for vacuum breaker; Models starting 3/23/04
	C000273	Bolt	2 required for shell support bracket to shell
	C000611	Nut	2 required for shell support bracket to shell
	C000567	Screw	4 required for vacuum breaker to valve panel
	N/A	Nut	4 required for vacuum breaker to valve panel; Models starting 3/23/04
	C002617P	Single Fan Harness	
1	C001772	Vacuum Breaker Cover	Models starting 3/23/04
2	C000390	Vacuum Breaker Assembly	
3	N/A	Grease Fitting	2 required; Models through 3/23/04
	C000549	Grease Fitting	2 required; Models starting 3/23/04
4	N/A	Grease Coupling	2 required; Models through 3/23/04
	C001789	Connector	2 required; Models starting 3/23/04
5	C000211	Fan	
6	C000317	Circuit Breaker	2 Amp
7	C000210	Fan Filter Guard Assembly	
	F200318900P	Filter	5 pack
8	C000677	Water Inlet Hose	
9	C000379	Supply Dispenser Hose	
10	C002636	Temperature Probe Assembly	
11	C000516	Lower Shell Support Bracket	Models starting 3/23/04
	C000988	Lower Shell Support Bracket	Electric heat models starting 3/23/04
12	225/10004/00	Thermostat Grommet	
13	C002055	Shell Support Brace	Models starting 3/23/04
14	C000445	Frame Assembly	

Main Assembly (Drawing 8 of 8)
Models CP040PHN1, CP040PHQ1, CP040PHX2, CPC40H, IP040PHN1, IP040PHN2, IP040PHQ1, IP040PHX2, IPH40H, JP040PHN1 and JP040PHQ1



PHM2947P_C002874

Main Assembly (Drawing 8 of 8)

REF	PART NO.	DESCRIPTION	COMMENTS
	C002421	Motor Cable	
	C000304	Motor Cable	
	C000994	Spring Clip	
	C002613	Drain Harness	
	C002614P	Drain Harness	
	F430144	Screw	4 required for motor to motor plate
	C000556	Washer	8 required for motor to motor plate
	803017	Nut	4 required for motor to motor plate
	F430124	Screw	1 required for motor plate to frame
	C000612	Screw	1 required for motor plate to frame for models through 3/23/04; 2 required for motor plate to frame for models starting 3/23/04
	C000177	Washer	1 required for motor plate to frame for models through 3/23/04; As required for motor plate to frame for models starting 3/23/04
	C000583	Washer	2 required for motor plate to frame for models through 3/23/04; 3 required for motor plate to frame for models starting 3/23/04
	90554	Hose Clamp	1 required for air trap
	F200213	Hose Clamp	2 required for overflow hose for models through 3/23/04; 4 required for overflow hose for models starting 3/23/04
	F200201	Hose Clamp	2 required for drain hose
	C003295	Drain T	Models starting 3/6/13; Replaces use of C001649 Reducing Connector
	C003314P	Alignment Tool	
1	20391	Hose Clamp	
2	C001053	Belt	
3	C000204	Motor	
4	C000689	Motor Bracket	
5	N/A	Belt Tension Spring	Models through 3/23/04
	C001790	Belt Tension Spring	Models starting 3/23/04
6	C000690P	Motor Pulley	
7	C000691P	Motor Bushing	
8	C000411	Drain Hose	
9	C003353	Drain Valve	
10	C001649	Reducing Connector	Models starting 3/23/04 through 3/6/13
11	C000676	Overflow Hose	
12	C000552	Hose	
13	C000223P	Cylinder Bushing	
14	C000222	Cylinder Pulley	
15	C000662	Air Trap Tube	Brass
16	C000654	Air Trap Tube Elbow	Rubber

Notes

Parts Index

		Carb Bearing	4.5
Α			15 19
			19
Adapt		Chemical Supply Controller	35
	C000424		
۸: T		Chemical Supply Harness	79
Alf II	ap Tube C00066293, 97, 101, 105		79
	C001232		79
Δir Tr	ap Tube Elbow	Circuit Breaker	
All III	C000654		91, 95, 99, 103
Aliant	ment Tool	C003135P	79, 81
Aligiti	C003313P101	F350217	79, 81
	C003314P	Circuit Breaker Kit	
	C003315P97		79, 81
	C003316P93	C0978P3	79, 81
Auxilia	ary Plumbing Assembly	Clean Filter Daily Decal	
	C00118763	F200061000	13
		Coil	
			55, 57, 59, 61, 63, 67, 69
В		Cold Plumbing Assembly	
D			59
Batte			61
	² 209/00505/04P35	Cold Water Valve Decal	9
Bearin	ng Housing		9
	C00005715	Connector	91, 95, 99, 103
	C000725 19		15, 17, 19, 21, 23, 25
Beari	ng Housing Assembly		15, 17, 19, 21, 25, 25
	C000058P	Contact Base	27
	C000728P		
	C001364P	Contact Block Switch	27
D:			27, 29
Bearii	ng Housing Puller Kit 1390P17, 21, 23, 25	Contactor	21, 20
	1390-1	C000308P	81
Doori	ng Lubrication Decal		81
Deam	C000508R1	Control Module Harness	
Belt	0, 10	C000865	35
Dell	C001053	Control Panel Decal	
	C001264	C001069	35
Relt T	ension Spring		35
DOIL 1	C001790 97, 101, 105	C001389	35
	C001800	Control Panel Insert	
Blind	Rivet	C000483	27, 29
	J1111905 53	C000484	27, 29
Bolt		Coupling	
	C000180 43, 45, 47, 49	C000420	55, 57
	C00027371, 73, 75, 77, 91, 95, 99, 103	Cover Decal	0.44
	C000430 51, 53		9, 11
	C000559	Cylinder Assembly Kit	0.7
	C000561		37
	F8549301		37 37
Bushi			37
ווופטם	F280233P93, 97, 101	Cylinder Bolt Shroud	
			37
		Cylinder Bushing	
		C000223P	93, 105
C			97, 101
Сар		Cylinder Lifter Rod	. ,
Cap	C001793		37

Cylinder Pulley C00022293, 97, 101, 105	Door Lock Harness C000867P51, 53
Cylinder Shaft C000068	Door Lock Kit C002996M51, 53
C000726	Door Lock Microswitch C00027851, 53
	Door Lock Plate C00068451, 53
D	Door Lock Slide Spring
Diaphragm and Guide Kit G582P355, 57, 59	C000276
DIN Coil F380986P55, 57, 59, 61, 63, 67, 69	F865410151, 53
F380987P 55, 57, 59, 61	Door Lock Solenoid Bracket C00302251, 53
DIN Valve Adapter Kit F838230155, 57, 59, 61, 63, 67, 69	Door Lock Spring B1235100153
DIN Valve Kit F852160167, 69	Door Lock Spring Cover C00068751, 53
Dispenser Assembly C000107	Door Lock Switch Slide C00027151, 53
Dispenser Door Handle	Door Magnet Mounting Bracket
C001788	C00299447, 49 Door Release Decal
C00052345, 49	C00069411, 13
Door Assembly C00007743, 47	Drain Harness
C000524	C00261393, 97, 101, 105 C002614P93, 97, 101, 105
C002726	Drain Hose
Door Bumper	C00041193, 97, 101, 105
C001546	F20016510093, 97, 101
Door Gasket	Drain T
C000521P45, 49	C00329593, 97, 101, 105
C003285 43, 47	Drain Valve
Door Glass	C00335393, 97, 101, 105
C000191	Drive Box Assembly
C000520P45, 49	C00105079, 81
Door Glass Gasket C000190	Drive Kit, 160-Series to PowerFlex 40
C00052245, 49	C00303187
·	C00303387
Door Glass Retainer C00051945, 49	C00303587
C000603	C003037
	C003039
Door Handle C001679P43, 45, 47, 49	C003041
	C00304587
Door Handle Bushing C000181	Dual Drain Harness
Door Handle Hinge Weldment	C00285893, 97
C000470 43, 45, 47, 49	
Door Handle Spring Bushing C00019243, 45, 47, 49	_
Door Handle Torsion Spring	E
C001786	Electric Heat Control Harness
Door Hinge	C00302079
C000604	Electric Heat Harness
C00068145, 49	C00272475
Door Hinge Bushing	C00275575
C000176 43, 45, 47, 49	C00275675
Door Latch	C002758
C001244 51, 53	C00283075
Door Lock Catch	Electric Heat Shell Assembly
C000185 51, 53	C000949
Door Lock Cover	C00095077
C000688	Electric Shock Danger Label F811550113
	ro11330113

Electrical Shock Label D502511R3	11	C00119681
	11	Fuse Holder C00119781
Emergency Stop Button Kit F200233700P	27	C00119781
Emergency Stop Pushbutton F200233500	27, 29	
EMI Filter	·	G
F330280P	83.85	
F330281		Gasket
F8053901P		C00170415, 19
F8053902		Grease Connector Box
		C00053931, 33
Exhaust Bracket C000323	79, 81	Grease Fitting
External Supply Connection Decal	,	C00054991, 95, 99, 103
F230917-1		Grease Shield C00006415
F8150201	13	
F		Н
		Hardware Kit
Fan C000211	91, 95, 99, 103	C00202317, 21, 23, 25
Fan Filter Guard Assembly	, , ,	Harness
C000210	91, 95, 99, 103	C00302887
Filter	. , ,	Heating Element
F200318900P	91 95 99 103	209/00562/3075, 77
F270305		Hinge
F270306P		C00178739, 41
Filter Housing Cap Gasket F270407		Hinge Block C00017543, 45, 47, 49
Flange and Nipple Assembly C001366		Hose C00055215, 17, 19, 21, 23, 25, 39, 41,
	55, 57, 59, 61, 65	91, 95, 99, 103, 105
Frame Assembly C000445	103	Hose Barb
C000780		F42195155, 57, 59, 61, 63
C000760		Hose Clamp
		F20020115, 23, 39, 41, 91, 93, 95, 97,
Front Cover C000606	44	99, 101, 103, 105
C000606	41	F20021393, 101, 105
Front Electrical Enclosure		F200222
C000213	35	20391105
Front Electrical Enclosure Assembly		3680115, 17, 19, 21, 23, 25, 41
C000432	35	90554
Front Electrical Enclosure Cover		
C000348	35	Hot Plumbing Assembly C00042655
Front Electrical Enclosure Rail		C00042655 C001664
C000218	33	
C000533		Hot Surface Warning Decal
Front Grease Shield	•	F200085000Ř19, 11, 13
C000729	19	F23138011
		Hot Surface Warning Label
Front Panel C001246	27	F861430113
C001248		Hot Water and Chemical Caution Decal
	29	F2000853009, 13
Front Panel Assembly C002966	27	Hot Water Valve Decal
C002966		F0231367-00R39
C002967		
C002969		
	∠ਖ਼	
Front Skirt Panel	00	1
C000314		Infrared Cable
C000530	31	Infrared Cable 210/00902/00P35
Front Supply Dispenser Nozzle		
C001017	39, 41	Inlet Power Cover C00125731, 33
Fuse	04	G00120731, 33

Inlet Valve Harness	C000791P97
C002608P 57, 61	C001051P101
C002610P55	Mount On Concrete Warning Label
C002611P 59	F824640113
Insert Rail	Mounting Bracket
C000636	C00037215, 17, 19, 23
C00101327	C00037379, 81
Inverter	C00037535
C000287 83, 85 C000288 83, 85	C00103721, 25
C000288 63, 63	
	N
J	Nipple
Jump Wire	C00099967, 69
C003291 51, 53	F42010755, 57, 59
	Nut
	C00006315
K	C00048719
N	C00056043, 45, 47, 49
Keymode Switch Assembly	C00056827, 29, 79, 81
C003024P27, 29	C00057443, 45, 47, 49, 51, 53
Keypad Controller	C00057651, 53 C00057851, 53
C000282P35	C000578
	C00123643, 45, 47, 49
	F43101137
	F43102427, 29, 31, 33, 35, 43, 45, 47, 49,
L	55, 57, 59, 61, 63, 71, 73, 75, 77, 91, 95
Logo Decal	F854940143, 45, 47, 49
C001038 11	80301743, 45, 47, 49, 93, 97, 101, 105
Lower Front Adjustment Bracket Assembly	
C002984	
C00298529	0
Lower Shell Support Bracket	O
C000079 91, 95	Overflow Hose
C00051699, 103	C00037793, 97
C000988 103	C000676101, 105
Lubricator	Overflow T-Drain Assembly
212/00022/00P15, 17, 19, 21, 23, 25	C00097193
<i>M</i>	P
	•
Magnet	Pinched Fingers Label
F839080147, 49	D502506R311
Magnetic Door Switch Bracket	Plate
C00299553	C00191615, 19
Main Board Controller Kit	Pop Rivet
C000281P35	F43121553 F43122347, 49
Motor 07 404 405	•
C000204	Power Block Terminal
C000205	C00029079 C00037079.81
Motor Bracket	
C00013093, 97 C000689101, 105	Power Distribution Block M41386581
Motor Bushing C000691P	PowerFlex 40 Drive C00303289
	C003032
Motor Cable 03 07 101 105	C003034
C000304	C003038 89
C002422	C00304089
,	C00304289
Motor Pulley C00022493	C00304487, 89
C000690P	C00304687, 89

N/A items do not appear in index.

Programming Key 124227, 29	70391101 81398	
Proximity Switch Assembly	Seal Plate	
C002637P 15, 17, 19, 21, 23, 25, 93, 97	C000065	15, 19
Push Decal	C000066	15, 19
F230303R2 11, 13	C000158	
	C000727	19
	Shell Assembly C000518	71
R	Shell Band and Clamp Weldment	
DO Nationals Assessables	C000659	73, 77
RC Network Assembly C002999	C001735	71, 75
RC Network Filter	Shell Front Assembly	
F330217P35	C002975	
Rear Electrical Enclosure Cover	C002976P	73, 77
C000173	Shell Front Gasket	74 71
Rear Enclosure Harness	C001762 C001763P	
C00086679		
Rear Grease Shield	Shell Front Gasket Kit F8513501	43 47
C00073019	Shell Gasket Shield	
Rear Panel	F601216	73, 77
C000051	Shell Support	,
C000525	C000093	73
Reducing Connector C001649 15, 17, 19, 21, 23, 25, 93, 97, 101, 105	Shell Support Brace	
Reed Switch Assembly	C002054	
C00300053	C002055	99, 103
Replacement Filter	Side Panel and Stiffener Assembly	0.4
F27040565	C002695 C002696	31
F27040665	C002096	
Roller Bearing	C002708	
C00015215	Single Dispenser Assembly	
C00048619	C000220	39
Rub Rail C000633	Single Fan Harness	
C000633	C002617P	95, 103
000101221	Single Front Dispenser Cover	
	C000605	39
0	Siphon Tube C001007	20.44
\$		39, 41
Screw	Spin Warning Decal F200085100	0 19
C000145 15, 17, 23	Spring	
C00056727, 29, 31, 33, 35, 51, 53, 55, 57,	C000431	51. 53
59, 61, 63, 79, 81, 91, 95, 99, 103 C00057251, 53	Spring Clip	
C000572	C000994	101, 105
C000612 51, 53, 93, 97, 101, 105	Spring Hose Clamp	
C000613 51, 53	C001004	41
C000614	Standoff	
C001018 15, 17, 19, 21, 23, 25	C000376	35
C001019 19, 21, 25 C001032 43, 45, 47, 49, 73, 75, 77	Steam Cord Assembly	07.00
C001093	C002748P	67, 68
C00114839, 41	Steam Hose C000736	60
C001294	C000735	
C001856	Steam Hose Insulation	
F430124	C001003	67. 69
F43090935, 39, 41, 79, 81	Steam Injector Tube Assembly	·
F43091027, 29, 35	F83638201	69
F43092039, 41	F8368201	67
F43092539, 41	Steam Option Assembly	
F430929	C001002	
F43093555, 57, 59, 61, 63 F43093879, 81	C001009	67
1 70000019, 01		

Steam Valve Mounting Bracket	Valve Rebuild Kit
C00098167, 69	F837950455, 57, 59, 61, 63
Steam Valve Mounting Flange	V-Ring Seal
C000733 67, 69	C00006915, 19
Street Elbow	C00007015
F42050255, 57, 59, 61	C00073119
F42170367, 69	
Stud	
C00060143, 45, 47, 49	
	W
Supply Dispenser Cup C000052	
C000052	Warning Label
	D500049R411
Supply Dispenser Hose	F8233501
C000379 91, 95, 99, 103	4432400113
Supply Signal Decal	Washer
' C0005069	C00007115
	C00014715, 17, 19, 21, 23, 25
	C00017743, 45, 47, 49, 93, 97, 101, 105
-	C000488
T	C00055693, 97, 101, 105
T	C00057115, 17, 19, 21, 23, 25, 27, 29, 31,
Tee F42040355, 57, 59	33, 35, 51, 53, 55, 57, 59, 61, 63, 79, 81
, ,	C00058337, 71, 73, 75, 77, 91, 93, 95,
Temperature Probe Assembly	97, 99, 101, 103, 105
C002636	C00058527, 29, 31, 33, 55, 57, 59, 61, 63
Thermostat	C00059071, 73, 75, 77
C00031879, 81	C00123937
Thermostat Grommet	F0431159-0037
225/10004/00 91, 95, 99, 103	F43113335, 79, 81
Tie Wrap Mounting Clamp	80361565
F14060279	Water Hose
Tilt Switch Assembly	F20011665
C002642P	F200128P55, 57, 59, 61, 63
	F200164
Top Panel C00005029	F200165
C000050	F20016665
	Water Inlet Hose
Transformer	C00037891, 95
C000203 79, 81	C00067799, 103
Trim Gasket	Water Line Caution Decal
C00062927, 29	F2307349
Triple Lip Seal	Water Reuse Hose
C002959 15, 17, 19, 21, 23, 25	C00041293
Tubing	Water Valve
C000628P 15, 17, 19, 21, 23, 25	C000436P55. 59
	Water Valve Repair Kit F380991P55, 57, 59, 61, 63
	F300991F33, 01, 03
V	
Vacuum Breaker Assembly	
C000390 91, 95, 99, 103	
Vacuum Breaker Cover	
C001772 95, 99, 103	
Vacuum Breaker Hose	
C00059971, 73, 93, 97, 101	
Vacuum Breaker Plug	
C000679	
Valve	
C000716P57	
F8322802 67, 69	
F8322909P	
Valve Kit F8379501P67. 69	
Valve Panel Assembly	
C00297931	
C002980 33	
N/A itama da not annoar in indov	

N/A items do not appear in index.