


# Maytag DG32CT 04 - CA & CM CONTROL CENTER & COMPONENTS

8

MODEL DG-32 CM

## CA - CM CONTROL CENTER & COMPONENTS



Copyright 1978 THE MAYTAG COMPANY • Newton, Iowa • Printed In U.S.A.

Maytag [Commercial Maytag DG32CT Dryer Parts](#) Parts Diagram 04 - CA & CM CONTROL CENTER & COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">210866</a>			Nut, Twin Speed
002	<a href="#">Y330078</a>			Cool-Down Bypass Switch
003	NLA		Not Available	TWIN FASTENER W/SCREWS
004	NLA		Not Available	SCREW, No.5-40 X 3/8
005	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
006	NLA		Not Available	CAGE NUT
007	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
008	<a href="#">Y330064</a>			Pilot Light
009	<a href="#">Y330077</a>			Door Switch
010	Y330079		Not Available	SWITCH, PUSH-TO-START
011	<a href="#">330081</a>			Timer - CA 60 Minutes
012	Y330082	<a href="#">330081</a>		Timer - CA 60 Minutes
013	Y330083		Not Available	CONTROL, TEMPERATURE
014	<a href="#">Y330092</a>			Terminal Block
015	Y330096	<a href="#">Y330233</a>		Mounting Plt, Cm Timer Accum.

016	NLA		Not Available	FRONT PANEL (WHT)
017	Y330100		Not Available	COIN BOX ASSEMBLY
018	NLA		Not Available	LOCK
019	NLA		Not Available	TIMER ACCUMULATOR - CM
020	NLA		Not Available	FRONT PANEL-WHITE
021	NLA		Not Available	MOUNTING PLATE (ACCUMULATOR)
022	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
023	NLA		Not Available	VAULT ASSEMBLY
024	330183		Not Available	TRANSFORMER
025	<a href="#">330184</a>			Timer Accumulator-25
026	NLA		Not Available	SCREW, BRACKET
027	331014	<a href="#">8281196</a>		Screw
028	NLA		Not Available	CABLE CLAMP
029	331026	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
030	331032	<a href="#">61002031</a>		Screw, Handle
031	<a href="#">331036</a>			Washer-Front Panel Screws
032	<a href="#">331041</a>			Button-Push-To-Start Switch
033	NLA		Not Available	TIMER DIAL - CA 60 MINUTES
034	<a href="#">331058</a>			Grommet-Temp. Control Tubin
035	<a href="#">331061</a>			Knob For Temperature Contro
036	NLA		Not Available	KNOB, TIMER
037	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
038	NLA		Not Available	SPACER - TEMP CONTROL COVER
039	331084		Not Available	SUPPORT ROD FOR UPPER DOOR
040	NLA		Not Available	HINGE RIVET
041	NLA		Not Available	SCREW-TEMP CONTROL LEVER
042	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
043	<a href="#">331151</a>			Lever-Temperature Control
044	NLA		Not Available	NUT, CONDUIT
045	NLA		Not Available	LIGHTING INSTRUCTIONS LABEL
046	NLA		Not Available	SCREW, TERMINAL BLOCK
047	NLA		Not Available	TWIN FASTENER
048	<a href="#">330112</a>			Switch For Actuator
049	<a href="#">Y330162</a>			Switch For Time Delay
050	NLA		Not Available	GROMMET, TEMP. CONTROL TUBIN

*the laundry company*<sup>®</sup>