


Maytag MDG76PCBWW 07 - MAIN DOOR SWITCH



Maytag Commercial Maytag MDG76PCBWW Dryer Parts Parts Diagram 07 - MAIN DOOR SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	A150006	150006		6-32 X 7 8
002	A152013	152013		6-32 Hex N
003	A153010	153010		6 Internal
004	A137005	W10146741		SDS Door S
005	A150445	150445		1 4-20 X 3
006	A882866	882866		Blk Main D
"	A883338			Assembly, Door Switch W/Housing
007	A150301	150301		8-18 X 7
008	A881151	W10148200		CRS Bottom
009	A881152	881152		CRS Top Hi
010	A153031	153031		1 4 Nylon