Whirlpool CAP2762EW1 01 - TOP AND CABINET, LITERATURE



Whirlpool Commercial Whirlpool CAP2762EW1 Washer Parts Parts Diagram 01 - TOP AND CABINET, LITERATURE
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8316457		Not Available	Literature Parts (Installation Instructions)
"	LIT8316462		Not Available	Literature Parts (Wiring Diagram)
"	LIT3951748		Not Available	Literature Parts (Tech Sheet)
"	LIT8316486		Not Available	Literature Parts (Repair Parts List)
2	3951142			Top
3	3353950			Spacer, Cabinet To Top
4	358473			Nut, Push-In
5	3358500			Panel, Front
6	62780			Clip, Top And Cabinet And Rear Panel
7	3355753			Clip, Static Ground
8	3356311			Screw And Washer, Lid Switch Shield
9	3393918	355214		Screw And Washer
10	3953152			Shield, Pressure Switch

11	3352632	285671	Switch-Lid
13	355274	W10119828	Screw, Lid Hinge Mounting
14	21097		Pad, Lid Hinge
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3976375	W10193854W10193854	Lid
20	358684		Strike, Lid Switch
21	3353812		Locator
22	356908		Bumper, Lid
23	718258	9741232	Screw, 8-18 X 5/8
26	98234		Clip, U-Bend
28	3353993		Screw 10-16 X .690
31	90016		Clip, Pressure Switch Hose
32	356907		Rivet, Plastic
35	3393258	3373329D	Screw
36	3353708	3976380	Panel, Right Hand
37	3353714	3976382	Panel, Left Hand
39	3353949		Pin, Locator
40	18776		Lock, Front Top
44	90406		Cage Nut, 5/16-18

the laundry company®
the laundry company®
the laundry company®