



MAYTAG A23CDL Parts Diagram - 06 - TRANSMISSION



Item	Part Number	Part Description
1	Y014827	WASHER, CENTER SHAFT
2	Y014839	COLLAR, DRIVE SHAFT
3	Y015629	BOLT, GRINDING CHAMBER (DRAIN)
4	NLA	PANEL COVER
5	Y015902	SPRING, AGITATOR
6	Y052740	NUT
7	Y056080	TRANS LUBE (AUTO, 34 OZ.)
8	200730	AGITATOR SHAFT
9	NLA	PANEL COVER
10	NLA	PANEL COVER
11	NLA	PANEL COVER
12	203383	TRANS & CENTER ASSY. (REG)
13	204967	GEAR KIT, POWER FIN AGITATOR
14	NLA	PANEL COVER
15	206602	SEAL, LIP (CENTER SHAFT)
16	210054	PINION
17	NLA	PANEL COVER
18	210183	GROOV-PIN, 1/4 X 1-1/4
19	210315	PINION
20	210632	GASKET
21	NLA	PANEL COVER
22	210690	SEAL, RUBBER
23	211089	LUG, STOP



Item	Part Number	Part Description
24	211090	WASHER, LOCK
25	211375	SCREW, STOP LUG (CNTR SHAFT)
26	211483	WASHER, SPLINED
27	211484	LUG WASHER
28	211486	SCREW (3/8-16 X 1/2 INCH)
29	NLA	PANEL COVER
30	212988	CENTER SHAFT