

Amana Residential Amana DG3630 Washer Parts Diagram 11 - DRUM LIGHT & COVER PLATE
Click on the part number to view part

| Item | Original Part Nui | mber Replaced By | Status | Part Description |
|------|-------------------|------------------|---------------|--|
| 5 | 53911 | | Not Available | COVER PLATE |
| 6 | Y00000000 | | Not Available | SEE NOTE FRONT FRAME AND AIR SHROUD |
| 7 | 51784 | | Not Available | SCREW,10B-16 X 1/2 HEX |
| | | | | |