


# Crosley CDE20C5A 02 - HEATER (ORIG. REV. A-C)

MASTER CARE

CDE20C5

HEATER



Issued 11/85

N-27-28

Crosley Residential Crosley CDE20C5A Dryer Parts Parts Diagram 02 - HEATER (ORIG. REV. A-C)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0500	<a href="#">LA-1044</a>		Element
"	<a href="#">25-7863</a>			Screw
2	<a href="#">53-0191</a>			Heater Housing Assembly
"	25-7819	<a href="#">M0217225</a>		Screw
3	53-0306	<a href="#">53-0771</a>		Thermostat, Hi-Limit
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
4	<a href="#">53-0285</a>			Bracket, Thermostat
"	25-7741	<a href="#">W10116760</a>		Screw
5	53-0166	<a href="#">53-1518</a>		Block, Terminal
"	25-7803	<a href="#">3400074</a>		Screw
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	<a href="#">25-3122</a>			Washer, Flat
"	25-0027	<a href="#">112432</a>		Nut