


Magic Chef WCZ1050W 07 - PUMP ASSY.



MODELS COVERED:		From serial Number
a	b	
W10AA-1 WCZ1050AM	W10AN-1 WCZ1050W	

FIRST PUBLICATION (4-84)

PM-1526-00

REVISION SHEET 0 (4-84)

A-10

Magic Chef [Residential Magic Chef WCZ1050W Washer Parts](#) Parts Diagram 07 - PUMP ASSY.
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	042526		Not Available	FLAT WASHER
2	042712		Not Available	LOCKWASHER
3	043656		Not Available	SCREW
4	044770		Not Available	SCREW
5	062798		Not Available	CLAMP
6	097095		Not Available	PUMP MTG GROMET
7	097863		Not Available	MAIN OUTLT HOSE
8	097978		Not Available	PUMP LOCK RING
9	097979		Not Available	PUMP IMPELLER
10	097980		Not Available	PUMP GASKET
11	097981		Not Available	BASE & GASKET
12	097982		Not Available	GASKET
13	097983		Not Available	FAN BLADE
14	098515		Not Available	HOSE CLAMP
15	098694		Not Available	DISCHARGE PUMP
16	Y098913		Not Available	PUMP BRACKET

