



[Maytag Residential Maytag A180 Washer Parts Parts Diagram 01 - 50HZ PARTS](#)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202158		Not Available	MOTOR 120-50
2	<a href="#">211948</a>			V Belt, Drive Pulley
3	<a href="#">211451</a>			Belt, Pump
4	<a href="#">201408</a>			Capacitor 120-50
5	<a href="#">211149</a>			Clip, Capacitor
6	<a href="#">205613</a>			Water Valve
7	<a href="#">203237</a>			No.17 Wire With Terminal
8	<a href="#">Y202496</a>			Pulley, Motor
9	<a href="#">211948</a>			V Belt, Drive Pulley
10	<a href="#">211451</a>			Belt, Pump
11	<a href="#">201101</a>			Capacitor
12	<a href="#">211149</a>			Clip, Capacitor
13	Y205684		Not Available	WATER VALVE 240-50
14	<a href="#">203237</a>			No.17 Wire With Terminal
15	<a href="#">206092</a>			Timer 240-50