Maytag DE303 08 - TUMBLER-BEIGE



Maytag Residential Maytag DE303 Dryer Parts Parts Diagram 08 - TUMBLER-BEIGE
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	313764		Not Available	SCREW
2	313915	31-3915		Tech Sheet
3	Y306660	33001106		Back, Tumbler
4	314820			Seal, Tumbler
5	Y310759			Screw, Tumbler Baffles
6	314158			Washer, Baffle To Tumbler
7	314802		Not Available	TUMBLER W/OUT BAFFLES
"	306663		Not Available	TUMBLER W/BAFFLES
8	314803	33001012		Baffle
9	314804	33001004		Baffle, Tall
10	306670		Not Available	TUMBLER FRONT----NA
12	Y310376			Clip, Door Switch Harness
13	Y313561			Screw----NA
14	Y306666	33001003		Screen, Lint
15	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	205810			Wire, Ground

17	Y313796			Lint Seal
18	310557			Washer
19	Y312961	W10116751		Screw
20	Y313795			Guide For Lint Screen
21	Y312964		Not Available	OUTLET DUCT - OUTER HALF
22	306656		Not Available	OUTLET DUCT & GRID ASSEMBLY
"	306657		Not Available	OUTLET DUCT & GRID
23	Y310632	1163839		Screw
24	306508			Tumbler Bearing Kit ----W
25	210720			Rivet, Bearing To Tumbler Frnt
26	Y314110	33002917		Screw, No.10-16
27	Y312959			Poly "V" Belt For Tumbler
28	410233	9703438		Ring-Retnr
29	312535			Washer, Vault Mounting Brk.
30	Y303373	12001541		Drum Roller/Washer Assembly--W
31	Y312948	6-3129480		Shaft- Tumbler
32	Y313347	312535		Washer, Vault Mounting Brk.
33	312538	33001443		Nut, Hex

the laundry company®
the laundry company®