Maytag DG19CD 01 - CD CONTROL PANEL & CONTROL CENTER



Maytag Residential Maytag DG19CD Dryer Parts Parts Diagram 01 - CD CONTROL PANEL & CONTROL CENTER
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	203188		Not Available	TIMER ACCESS DOOR (WHT)
003	203188L		Not Available	ACCESS DOOR-ALMOND
004	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
005	NLA		Not Available	MTG. STRAP----NA
006	205423	208883		Coin Box K
007	205423L	208883		Coin Box K
008	205423M	208883		Coin Box K
009	205810			Wire, Ground
010	NLA		Not Available	CIRCUIT BOARD ASSY
011	206794		Not Available	SWITCH (W/NUT)
012	206795		Not Available	COIN DROP METER ASSY
013	206795L		Not Available	COIN DROP METER ASSY
014	NLA		Not Available	COIN DROP METER ASSY
015	Y206800	207766		Transformer

016	206824	W10133335		Relay, Motor
017	206828			Battery
018	211252			Screw, Ground Wire
019	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
020	212276	W10116760		Screw
021	212328	W10139762		Hex Nut, 3/4-27
022	213035			Bolt, Locking
023	213750	W10133266		Cam-Lock
024	214660			Gasket, Control Center
025	215003			Fastener, Panel And Bracket
026	215506			Screw, Control Panel Overlay
027	215510		Not Available	SUPPORT, PC BOARD
028	215515		Not Available	COVER, DISPLAY
029	215517	W10131113		Push Button
030	215526			Screw, Circuit Board
031	215527	W10140652		Screw, 6-20 X 1/2
032	Y305191		Not Available	TOP COVER-WHITE
033	NLA		Not Available	TOP COVER-ALMOND
034	NLA		Not Available	TOP COVER-HARVEST WHEAT
035	NLA		Not Available	CONTROL COVER (WHT)
036	NLA		Not Available	CONTROL COVER ASSY----NA
037	NLA		Not Available	CONTROL COVER ASSY
039	NLA		Not Available	WIRE HARNESS
040	NLA		Not Available	WIRE HARNESS
041	306694			Backup Plate With Switch
042	NLA		Not Available	BACK BRACKET, CONTROL PANEL
043	NLA		Not Available	BACK BRACKET FOR CONTROL PANEL
044	NLA		Not Available	BACK BRACKET FOR CONTROL PANEL
045	NLA		Not Available	CONTROL PANEL
046	910181			Lockwasher, Terminal Block
047	910309			Washer, Mounting Strap
048	912077			Locknut, Reader Harness

the laundry company®