


# Maytag GA9800 04 - CONTROL PANEL

SECTION: CONTROL PANEL

MODEL: A9800



Issue Date: 4/90

30

Maytag [Residential Maytag GA9800 Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

[Click on the part number to view part](#)

| Item | Original Part Number   | Replaced By               | Status        | Part Description                                |
|------|------------------------|---------------------------|---------------|---|
| 1    | 212949                 | <a href="#">22001866</a>  |               | Screw, Relay                                    |
| 2    | <a href="#">214809</a> |                           |               | Back Up Plate                                   |
| 3    | 215821                 |                           | Not Available | CAP, KNOB                                       |
| 4    | 410296                 | <a href="#">596669</a>    |               | Clamp, Manifold                                 |
| 5    | 207385                 |                           | Not Available | CONTROL PANEL                                   |
| 6    | <a href="#">214897</a> |                           |               | Pad, Control Panel                              |
| 7    | 207215                 |                           | Not Available | END CAP LH                                      |
| 8    | 207216                 |                           | Not Available | END CAP RH                                      |
| 9    | <a href="#">214894</a> |                           |               | Fastener, End Cap                               |
| 10   | <a href="#">207360</a> |                           |               | Infinite Level Press Switch                     |
| 11   | <a href="#">214872</a> |                           |               | Palnut, End Cap Note: Nut, Lamp Holder          |
| 12   | <a href="#">211605</a> |                           |               | Bezel, Timer Dial                               |
| 13   | <a href="#">207365</a> |                           |               | 2 Button Switch                                 |
| 14   | <a href="#">210932</a> |                           |               | Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct |
| 15   | 211168                 | <a href="#">W10139210</a> |               | Screw, 8-18 X 5/16                              |

|    |                        |                           |                                |
|----|------------------------|---------------------------|--------------------------------|
| "  | 211168                 | <a href="#">W10139210</a> | Screw, 8-18 X 5/16             |
| 16 | 213117                 | <a href="#">67006908</a>  | Screw, Ice Rack                |
| "  | 213117                 | <a href="#">67006908</a>  | Screw, Ice Rack                |
| 17 | 213966                 | <a href="#">3400014</a>   | Screw                          |
| 18 | 207369                 | Not Available             | SPEED CONTROL SWITCH - 4 BUTTO |
| 19 | <a href="#">211065</a> |                           | Spring, Index Wheel            |
| 20 | <a href="#">207371</a> |                           | Timer                          |
| 21 | 215827                 | Not Available             | TIMER DIAL SKIRT               |
| 22 | <a href="#">215828</a> |                           | Knob, Timer                    |
| 23 | 205033                 | <a href="#">22205033</a>  | Motor- Tim                     |
| 24 | <a href="#">207366</a> |                           | Temp Control Switch - 5 Button |
| 25 | 207380                 | Not Available             | WIRE HARNESS                   |

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>