


Maytag GDG31CA 03 - ACCUMULATOR & COMPONENTS-DOUBLE COIN

MODEL DG31CM

CM TIMER ACCUMULATOR & COMPONENTS - SINGLE COIN



- 3-30112 Switch for timer motor
- 3-30113 Timer motor
- 3-30116 Timing cam kit - 7-1/2 min. - 8 pins on cam
- 3-30117 Timing cam kit - 10 min. - 6 pins on cam
- 3-30145 Timer accumulator complete - .10
- 3-30162 Switch for time delay
- 3-30163 Coin handling mechanism
- 3-30164 Meter plate assembly
- 3-30165 Coin retainer spring and screw kit
- 3-31118 Coil spring for pawl
- 3-31121 Coil spring for detent arm
- 3-31122 Index lever and switch actuator
- 3-31147 Coil spring for coin carrier return

Maytag Residential Maytag GDG31CA Dryer Parts Parts Diagram 03 - ACCUMULATOR & COMPONENTS-DOUBLE COIN

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	NLA		Not Available	TIMER ACCUMULATOR
002	330112			Switch For Actuator
003	330113			Timer Motor
NI	NLA		Not Available	METER PLATE ASSEMBLY
"	NLA		Not Available	COIN HANDLING ASSEMBLY
006	330116		Not Available	TIMING CAM - 8 PINS
007	330117		Not Available	TIMING CAM - 6 PINS
NI	NLA		Not Available	COIL SPRING, PAWL
"	NLA		Not Available	SIDE SPRING-COIN RETAINER
"	NLA		Not Available	BOTTOM SPRING-COIN RETAINER
"	NLA		Not Available	COIL SPRING, DETENT ARM
"	NLA		Not Available	INDEX LEVER-SWITCH ACTUATOR
"	331153			Coil Spring F/Carrier Retur