


# Maytag GDG34CQ 03 - ELECTRONIC CONTROL ASSEMBLY

## MODEL DG34CD-CQ

### CD-CQ ELECTRONIC CONTROL ASSEMBLY



Maytag Residential Maytag GDG34CQ Dryer Parts Parts Diagram 03 - ELECTRONIC CONTROL ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y310632	<a href="#">1163839</a>		Screw
NI	Y330264		Not Available	WIRE HARNESS
"	Y330265		Not Available	WIRE HARNESS-DUAL CONTROL
"	Y330266		Not Available	MEMBRANE SWITCH
005	Y330268		Not Available	COIN ACCEPTOR ASSEMBLY \$.25
NI	NLA		Not Available	COIN ACCEPTOR ASSEMBLY \$.10
007	Y330270		Not Available	COIN SWITCH
008	<a href="#">36001001</a>			Printed Circuit Board
"	<a href="#">36001002</a>			Sensor
"	Y330273	<a href="#">Y330316</a>		Electronic
"	<a href="#">Y330315</a>			Switch Assembly
"	Y330319		Not Available	WIRE ASSEMBLY
"	<a href="#">Y330320</a>			Harness, Heat Sensor
009	<a href="#">331233</a>			Plate For Electronic Contro

010	<a href="#">331234</a>		Spacer For Circuit Board
011	331235	<a href="#">701719</a>	Nut, Hex
NI	NLA		Not Available
			BAIL FOR COIN RETURN
013	<a href="#">331237</a>		Screw
NI	NLA		Not Available
			LOCK WASHER
"	NLA		Not Available
			BUMPER
"	NLA		Not Available
			LABEL - \$.25
"	NLA		Not Available
			LABEL - \$.10-\$.25

