



[Maytag Residential Maytag LA181 Washer Parts](#) Parts Diagram 01 - 50HZ PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	202158		Not Available	MOTOR 120-50
2	211948			V Belt, Drive Pulley
3	211451			Belt, Pump
4	201408			Capacitor 120-50
5	211149			Clip, Capacitor
6	205613			Water Valve
7	203237			No.17 Wire With Terminal
8	Y202496			Pulley, Motor
9	211948			V Belt, Drive Pulley
10	211451			Belt, Pump
11	201101			Capacitor
12	211149			Clip, Capacitor
13	Y205684		Not Available	WATER VALVE 240-50
14	203237			No.17 Wire With Terminal
15	206092			Timer 240-50