


Maytag MAH5500AWW 04 - CONTROL PANEL



Maytag [Residential Maytag MAH5500AWW Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22002010			Hose, Pressure Switch
2	22001664			Timer Knob Insert/Cap
3	22003807			Medallion, Console
"	22003806			Medallion, Console
"	22003010			Panel, Control
4	22002268			Switch, 4 Position
5	22002278	22002874		Switch- OP
6	903115			Lock Light
"	22002281			Indicator Light
"	22001948			Lens, Indicator Light
7	22003012	22003013		Button, Push To Start
"	22002787			Switch, Start/Stop
8	22003287			Harness, Main Wire
"	22003014			Harness, Main Wire
9	22002867			Timer
"	22001662	8534058		Screw

10	22002282		Bezel, Timer Dial
11	22001659		Timer Knob - Grey
12	22001788		Button, Switch
13	22002994		Switch, Pressure
14	22002270		Switch, Fabric
15	22001789		Button, Switch
16	33002286	Not Available	CONSOLE (WHT)
17	22002345	Not Available	TIE, WIRE
"	22001996	3370225	Screw
"	22002178		Bracket, Air Dome Hose
18	22001996	3370225	Screw
"	Y22002339	8534058	Screw
"	33001806	Not Available	BACK, CONSOLE PANEL
19	22002284		Bracket
"	22002788	22002989	Board, Control
20	2201907		Manual, Use And Care
"	22003419		Manual, Use And Care
"	22003484	Not Available	SCRIPT, U & C VIDEO (SPN)
"	22003485		Script, U And C Video
"	16008373	Not Available	MANUAL, SERVICE-NO REFUND
21	22002899		Video, U And C
"	22002304	22003485	Script, U And C Video

