


Maytag MDE10PSAGL 01 - CONTROL PANEL



Maytag [Residential Maytag MDE10PSAGL Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001020			Panel, Control
002	215506			Screw, Control Panel Overlay
003	205810			Wire, Ground
004	215527	W10140652		Screw, 6-20 X 1/2
"	306694			Backup Plate With Switch
005	215517	W10131113		Push Button
006	NLA		Not Available	PLATE, BACKUP (WHT)
007	NLA		Not Available	CONSOLE (WHT)
008	212276	W10116760		Screw
009	215003			Fastener, Panel And Bracket
010	208045			Harness, Wire Sensor Switch To Circuit Brd
"	22001361			Connector, Edgeboard
011	207766			Transformer
"	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
012	33001249			Battery, Control Board

"	912077		Locknut, Reader Harness
"	NLA	Not Available	BOARD, CONTROL
"	NLA	Not Available	SUPPORT, BATTERY
"	Y215513		Standoff, Circuit Board
013	314531		Connector, Edgeboard
"	33001283		Wire Harness, Main
"	33001428		Wire Harness, Main
014	33001208		Cover, Display
015	211252		Screw, Ground Wire
016	215526		Screw, Circuit Board
017	206799		Optic Switch Assembly
"	NLA	Not Available	CONNECTOR, EDGEBOARD- --NA

the laundry company[®]

the laundry company[®]

the laundry company[®]