Maytag MDG3000AWQ 04 - DOOR (MDG3000AXQ/AWQ)



Maytag Residential Maytag MDG3000AWQ Dryer Parts Parts Diagram 04 - DOOR (MDG3000AXQ/AWQ)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33001767			Seal, Shroud
2	22002033	33002597		Hook, Security
3	33002116		Not Available	LABEL, SAFTEY
"	33002379			Shroud
4	22001995			Screw Note: Screw, Tumbler Front And Shroud
5	33001768			Screw, Shroud Note: Screw, Shroud And Outlet Duct
6	33001508	W10169313		Switch-Dor
7	33001760			Bracket, Hinge
8	33001174	LA-1003		Door Catch Kit
9	Y304578	LA-1003		Door Catch Kit
"	33001791	306436		Door Latch Kit--W
10	33002094			Seal, Door
11	22002038			Clip, Door
12	33001793			Bracket, Strike
13	33001761			Strike, Door

14	22002039			Clip, Door
15	33001763			Plug, Inner Door
17	22001817			Sheet, Sound Damper
"	22002661			Panel, Door
"	33001893		Not Available	LABEL, OPEN DOOR (DRYER)
18	33001759			Hinge, Door
19	22002062	98006631		Screw
20	33002351			Screw
21	33002349			Cover, Hinge Hole
22	33001787			Screw, Hinge Note: Screw, Hinge Hole Cover
23	22002012			Screw, Hinge Note: Screw, Hinge Bracket
24	33001221	22001817		Sheet, Sound Damper
"	33001867			Pad, Front
"	22002663		Not Available	PANEL, FRONT (BISQ)

the laundry company®
the laundry company®
the laundry company®