Maytag MFR35MCAVS 17 - SOAP BOX & TOP COVER ASSEMBLY



Maytag Residential Maytag MFR35MCAVS Washer Parts Parts Diagram 17 - SOAP BOX & TOP COVER ASSEMBLY
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23002892	23001001		Cover, Top
002	23001003			Rubber Cover, Soap Box
003	23002893			Lath, Rubber Cover Soap Hopper
004	23001005			Rubber Hose, Soap Box
005	23001006			Lock, Top Panel
006	23001007			Washer M21x27x1
007	23001008			Nut, Lock
008	23001009			Hook, Lock
009	23001011			Nut
010	23001012			Screw
011	23001636	23002674		Spring, Lock Washer
012	23002652			Nut
013	23001015			Rubber Seal, Soap Box
014	23001016			External Soap Hopper
015	23001017			Soap Hopper Insert
016	23001018			Syphon Hose

017	23001019			Fabric Softner Insert
018	23001020			Insert Retainer
019	23001021			Prewash Diverter
020	23001022			Mainwash Diverter
021	23001023			Fabric Softner Diverter
022	23001024	23003782		Screw 3 Stainless Steel Lu
023	23001025			Clamp, Hose
024	23002462			Screw Lu
025	23001027			Washer
026	23002756			Lockwasher
027	23002894	23003484		Screw
028	23001030			Hinge, Top Cover
029	23001031			Shaft, Hinge
030	23001032			Spring Clip
031	23001033			Rivets, Blind Lu
032	23002436		Not Available	NUT (M6)

the laundry company®
the laundry company®
the laundry company®