Whirlpool 2DLXR7244MQ0 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool 2DLXR7244MQ0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8318342		Not Available	Literature Parts (Installation Instructions)
"	LIT8539732		Not Available	Literature Parts (Use & Care Guide)
"	LIT3954578		Not Available	Literature Parts (Wiring Diagram)
"	LIT4313896	4313896		Do-It-Yourself Repair Manuals
2	8274315		Not Available	Top (White)
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3356311			Screw And Washer, Lid Switch Shield
9	3949237	3949247		Switch-Lid
13	3351355	W10119828		Screw, Lid Hinge Mounting

15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3361411	W10193874	Lid
20	358684		Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	90016		Clip, Pressure Switch Hose

the laundry company®
the laundry company®
the laundry company®