


Whirlpool 3XWTW5105SQ0 02 - CONTROLS AND REAR PANEL PARTS

CONTROLS AND REAR PANEL PARTS

For Model: 3XWTW5105SQ0
(White)



W10112704

3

Whirlpool [Residential Whirlpool 3XWTW5105SQ0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3347868	W10339879		Tie, Cable
2	3398893	3395559		Wire
3	3949382			Hose, Water Inlet
"	3949383			Hose, Water Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8541686			Panel, Rear
7	62747			Pad, Rear Panel
8	W10122138	W10096921		Drain Hose Assembly
9	W10163650			Timer, Control
10	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366849	W10339228		Switch-WL
13	3948814			Bracket, Control

14	W10111545		Cord, Power
15	8559337	285777	Relief-Str
16	8271369	279962	Endcap
17	3351614		Screw, Gearcase Cover Mounting
18	3360397		Valve, Water Mixing
19	8541668		Clamp, Hose
20	357572	W10113937	Clip, Grounding
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	3951198		Fuse
29	3400073		Screw, Ground
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8541669		Bucket, Drain Hose
34	8541658		Bucket, Drain Hose
35	3400818		Screw, Timer Mounting
36	W10095620		Panel, Console
37	3357397		Adapter, Water Inlet Hose
38	8566022		Knob, Timer
39	8566018		Dial,
40	8536939		Clip, Knob
41	8565944		Knob, Control
42	388326		Screw, 8-18 X 1.25
43	62863	3390631	Screw, 10-16 X 3/8
44	8271363	279962	Endcap
45	8314879		Shield, Inlet Valve
46	3349557		Retainer, Harness
47	3956874		Harness, Wiring

