Whirlpool 7MWT96725WW0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool 7MWT96725WW0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8533252			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3949550			Washer
4	389386			Agitator
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
7	3354845			Clip, Agitator
8	8543666			Washer, Agitator
9	3363662	285748		Cam-Agitator
10	3366877	80040		Dog-Agitator
11	3363661			Bearing, Driven Cam
12	21366			Nut, Spanner
13	8526016	W10389328		Clothes Container, Assembly
14	387240			Ring, Balance
15	2219077			Clip, Pressure Switch Hose
16	63849			Strain Relief, Power Cord

17	389140		Tub Block, Basket Drive
18	383727		Gasket, Centerpodt
19	3347780	353244	Hose, Pressure Switch
20	3347674	285727	Agitator
21	3350389	285587	Washer
22	389141	3360824	Auger, Agitator
23	8577198		Filter, Lint

the laundry company®
the laundry company®
the laundry company®