


Whirlpool IJ40001 02 - CONTROLS AND REAR PANEL PARTS



6178554

3

Whirlpool [Residential Whirlpool IJ40001 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3400073			Screw, Ground
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	3357027			Nozzle, Hose Drain
5	8318255	8568314		Strap, Console
6	3357976			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3946451			Timer, Control
10	388326			Screw, 8-18 X 1.25
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping

12	3366849	W10339228	Switch-WL
13	3948814		Bracket, Control
14	3948063	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	9740848		Screw, Mixing Valve Mounting
18	3952164	285805	Valve-Inlet
19	90864	3351614	Screw, Gearcase Cover Mounting
20	8318201	8318046	Clip, Capacitor
21	370451	596669	Clamp, Manifold
22	62662	3357328	Hose, Vacuum Break
23	371503	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	8519200		Support, Rear Panel
26	3361805	W10358149	Drain Hose Assembly
27	3366912	356138	Clamp, Hose
28	3351614		Screw, Gearcase Cover Mounting
29	661606	8572717	Capacitor, Motor Start
30	3363366	616099	Clamp
31	660628	285655	Clamp, Hose
32	3951449	285871	Hose
36	3400064		Screw, Timer Mounting
39	3954230	Not Available	Panel, Console
44	8274290	3364291	Knob, Timer
45	8274331	Not Available	Dial, Timer
47	8271339	3957799	Knob, Control
50	62863	3390631	Screw, 10-16 X 3/8
51	8271359	279962	Endcap
52	3366913	3357331	Clamp, Drain
53	3390647	488729	Screw
54	3955023		Harness, Wiring

