


Whirlpool IM41000 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: IM41000
(White)

AUTOMATIC
WASHER



8-03 Litho in U.S.A. (drd)

1

Part No. 6180084

Whirlpool [Residential Whirlpool IM41000 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3361044		Not Available	Literature Parts (Installation Instructions)
"	LIT3955167		Not Available	Literature Parts (Use & Care Guide)
"	LIT8542052			Literature Parts
"	LIT3955531		Not Available	Literature Parts (Energy Guide)
2	8274315		Not Available	Top (White)
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	90016			Clip, Pressure Switch Hose
8	3356311			Screw And Washer, Lid Switch Shield
9	3949237	3949247		Switch-Lid
10	3357011	308685		Side Trim)
13	3351355	W10119828		Screw, Lid Hinge Mounting

15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3361411	W10193874	Lid
20	358684		Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

