


Whirlpool MGD5830TW0 02 - CABINET PARTS



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10118322

3

Whirlpool [Residential Whirlpool MGD5830TW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	4331106		Screw, No.10-32 X 7/16
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	8541400			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3404162			Clamp, Motor
7	3396805	280043		Panel-Rear
8	3403630			Plug, Strike Hole
9	3980175			Clamp, Elbow
10	3406107			Door Switch Assembly
11	697773	3395530		Screw
12	98669			Lock, Front Top
13	341029			Clamp, Pipe Door Spring
14	3404413			Plug, Hinge Hole
15	18849			Pad, Top Hinge
16	3392100	49621		Feet-Leveling

"	279810		Foot-Optional
17	660658		Clamp, Motor Mounting 343481 685441
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	18776		Lock, Front Top
21	3403447	279854	Panel
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	3405246		Seal, Door Push-To-Start
27	342055	488627	Screw
28	3405514	W10362431	Hinge And Pin Assembly
29	8066206	279827	Motor-Drve
30	8066184		Pulley, Motor
31	3400500		Bolt, 3405245 5/16-18 X 3/4
33	3403431		Strike, Panel
35	3402341		Door, Inner
36	3402335		Door, Front
37	8565970		Handle, Door
38	3406129		Seal And Bearing Assembly
39	3394975		Plug, Front Panel
40	344020	3401402	Cord, Power
41	3394083		Clip, Front Panel
42	8066217		Hinge, Top
43	691366		Idler And Pulley Assembly
44	8066065	341241	Belt
45	348780		Base, Motor
46	8318272	W10465748	Burner-Gas

the laundry company[®]

the laundry company[®]