


Whirlpool RAB2121PW3 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: RAB2121PW3
(White)

AUTOMATIC
WASHER



11-05 Litho in U.S.A. (drd)

1

Part No. 8181015

Whirlpool [Residential Whirlpool RAB2121PW3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3958075		Not Available	Installation Instructions
"	8578234		Not Available	Use & Care Guide
"	3955913		Not Available	Feature Sheet
"	8546684		Not Available	Wiring Diagram
"	3957471		Not Available	Energy Guide
2	8541621			Top
4	357213			Nut, Push-In
5	63128			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3351614			Screw, Gearcase Cover Mounting
11	8318084			Switch, Lid
13	3351355	W10119828		Screw, Lid Hinge Mounting
15	8318088			Hinge, Lid
16	54583			Hinge, Lid

17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542382	W10193857	Lid
22	9724509		Bumper, Lid
23	3390631		Screw, 10-16 X 3/8

