Whirlpool WTW5900TW0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool WTW5900TW0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8575076	8575076A		Dispenser
2	3354733	W10074580		Cap, Barrier
3	3348855	W10072840		Fabric Softener
4	358237			Screw And Washer
5	3949550			Washer
6	3951744			Agitator Assembly
7	3951682	285809		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3952374			Bearing, Driven Cam
10	3363003			Mover, Clothes
11	3951608			Spacer, Thrust
12	3951632			Agitator
13	3954507	W10213410		Ring-Tub
14	8318246	W10213410		Ring-Tub
15	3359585	3976308		Gasket, Tub Ring
16	3354845			Clip, Agitator

17	8543666		Washer, Agitator
18	21366		Nut, Spanner
19	8519788	387240	Ring, Balance
20	2219077		Clip, Pressure Switch Hose
21	3347780	353244	Hose, Pressure Switch
22	389140		Tub Block, Basket Drive
23	8526016	W10389328	Clothes Container, Assembly
24	8283125		Tub
25	3948705		Hose, Bleach
26	383727		Gasket, Centerpodt

the laundry company®
the laundry company®
the laundry company®