


Whirlpool WTW6200VW1 02 - CONTROL PANEL PARTS



Whirlpool [Residential Whirlpool WTW6200VW1 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10268788			Control Unit Assembly, Machine And Motor
2	W10130502			Gasket, Valve Tray
3	8565304			Tray Assembly, Console
4	8565259			Gasket, Console/Tray
5	8577408	W10364988		Valve
6	8574957			Knob, Assembly
7	W10051149			User Interface
8	W10004990			Screw, 6-20 X 1.2
9	W10183845			Console
10	8564265			Cover, Rear- User Interface
11	W10003770			Screw, 6-19 X 1/2
12	W10022060			Nut, Push-In
13	3351614			Screw, Gearcase Cover Mounting
14	8565324			Screw, 10-16 X 1.75
15	8281136			Screw, 10-16 X 3/4

16	3407203		Cord Assembly, Power
17	98460		Nut, Push-In
18	W10242307	16123	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
19	W10194208	89503	Hose-Inlet
"	8571378	89503	Hose-Inlet

