

FOR IMMEDI	ATE ATTENTION O	F YOUR SERVICE	CE DE	PARTMENT
LAUNDRY PRODUCTS	REFRIGERATION PRODUCTS	KITCHEN PRODUCTS		L8178730 February 2008
THIS SERVICE POIL	NTER APPLIES TO THE FOLI	LOWING BRANDS:	<u>'</u>	
Whirlpool Home Papelances	KitchenAid	■ Z IJENN-AIR.		MAYTAG [®]
□ A mana	Roper TM BY WHIRLPOOL CORPORATION	☐ Admiral 7 /		Magic Chef*

Whirlpool Front Load Steam Duet Washer

Will not immediately start after delivery

Model Numbers: WFW9600T*
(*= all colors, all engineering digits)
Serial Numbers: All

CONDITION:

Installers or customers may believe that the front load washer just installed is a "DOA" unit.

CAUSE:

Steam assist models have an Automatic Adjustment Mode built into the electronics. The Automatic Adjustment Mode is generally 90-100 seconds but may take up to 5 minutes at the beginning of each cycle before the washer begins to fill. This Automatic Adjustment Mode is necessary to ensure the most efficient operation of the washer.

RESOLUTION:

Advise the customer that the washer will go into the Automatic Adjustment Mode every time the washer is turned on. In the future, a label will be attached to the door advising the installer and the customer of this calibration mode.