


## Dexter WCAD20KCS-12 (T300) Gear Motor Door Lock Assembly



Dexter [Commercial Dexter WCAD20KCS-12 \(T300\) Washer Parts](#) Parts Diagram Gear Motor Door Lock Assembly  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
*	<a href="#">9892-014-001</a>			Actuator Assembly (Includes 1-10, Rod NOT included)
11	<a href="#">9545-012-027</a>			Screw Pnhdcr, 10-32 UNFx0 .75
10	<a href="#">9545-031-011</a>			Screw #6 x 5/16"
9	<a href="#">9545-044-003</a>			Screw -Hxwshrhdslsems, 6-32 x 3/16
8	<a href="#">9914-137-011</a>			Motor & Gear Train (complete)
7	<a href="#">9534-350-001</a>			Spring - Extension
6	<a href="#">9586-001-001</a>			Thermoactuator 120 V
5	<a href="#">9001-063-001</a>			Arm - Door Lock
4	9538-157-021		Not Available	Spacer, Plastic
3	9029-204-001		Not Available	Bracket Slide Lock

2	9985-189-001	Not Available	Bracket Assy, Slide - Unlock
1	9985-190-001	Not Available	Bracket Assy, Slide Lock Actuator
*	<a href="#">9497-225-011</a>		Rod, Door Lock

**WWS**  
*the laundry company*<sup>®</sup>

**WWS**  
*the laundry company*<sup>®</sup>

**WWS**  
*the laundry company*<sup>®</sup>