


# Maytag DG33CA 04 - CONTROL CENTER & COMPONENTS

## MODEL DG33CA-CM CA-CM CONTROL CENTER & COMPONENTS



8

Maytag [Commercial Maytag DG33CA Dryer Parts](#) Parts Diagram 04 - CONTROL CENTER & COMPONENTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.5-40 X 3/8
002	NLA		Not Available	CAGE NUT
003	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
004	<a href="#">Y330064</a>			Pilot Light
005	<a href="#">Y330073</a>			Valve, Shut-Off
006	Y330079		Not Available	SWITCH, PUSH-TO-START
007	<a href="#">330081</a>			Timer - CA 60 Minutes
008	Y330083		Not Available	CONTROL, TEMPERATURE
009	<a href="#">Y330092</a>			Terminal Block
010	NLA		Not Available	FRONT PANEL-WHITE
011	NLA		Not Available	(ALMOND)
012	NLA		Not Available	(HARVEST WHEAT)
013	NLA		Not Available	LOCK
014	NLA		Not Available	PART NOT USED
015	NLA		Not Available	FRONT PANEL-WHITE
016	330108L		Not Available	FRONT PANEL-ALMOND

017	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
018	NLA		Not Available	MOUNTING PLATE (ACCUMULATOR)
019	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
020	<a href="#">330184</a>			Timer Accumulator-25
021	<a href="#">Y330294</a>			COIN BOX ASSEMBLY
022	<a href="#">Y330226</a>			Wire, Ignition Control Assembly
023	<a href="#">Y330230</a>			Ignition Control Assembly
024	<a href="#">Y330231</a>			Transformer
025	<a href="#">Y330233</a>			Mounting Plt, Cm Timer Accum.
026	Y330239		Not Available	GAS VALVE - NAT
027	NLA		Not Available	GAS VALVE (LPG)
028	Y330242		Not Available	VAULT ASSEMBLY
029	NLA		Not Available	TIMER ACCUMULATOR (.25-.10)
030	NLA		Not Available	TIMER ACCUMULATOR (.10)
031	NLA		Not Available	TIMER ACCUMULATOR (.25)
032	Y330250		Not Available	COIL ON GAS VALVE
033	<a href="#">Y330253</a>			Fuse
034	<a href="#">Y330254</a>			Fuse Block
035	NLA		Not Available	SCREW, BRACKET
036	331014	<a href="#">8281196</a>		Screw
037	331026	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
038	331032	<a href="#">61002031</a>		Screw, Handle
039	<a href="#">331036</a>			Washer-Front Panel Screws
040	<a href="#">331041</a>			Button-Push-To-Start Switch
041	NLA		Not Available	TIMER DIAL
042	<a href="#">331061</a>			Knob For Temperature Contro
043	NLA		Not Available	KNOB, TIMER
044	NLA		Not Available	GAS SUPPLY LINE-28 1/2 INCH
045	NLA		Not Available	SPACER - TEMP CONTROL COVER
046	331084		Not Available	SUPPORT ROD FOR UPPER DOOR
047	331101		Not Available	BEZEL FOR TIMER-ACCUMULATOR
048	NLA		Not Available	HINGE RIVET
049	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
050	<a href="#">331151</a>			Lever-Temperature Control
051	NLA		Not Available	NUT, CONDUIT
052	NLA		Not Available	GROMMET, TEMP. CONTROL TUBIN
053	NLA		Not Available	DECA, LIGHTING & CLEARANCE
054	<a href="#">331230</a>			Clip