


# Amana DB8181N 01 - HOPPER/START SW/SHREDDER & SOUND SHELL



## HOPPER, START SWITCH, SHREDDER AND SOUND SHELL

Amana [Residential Amana DB8181N Washer Parts](#) Parts Diagram 01 - HOPPER/START SW/SHREDDER & SOUND SHELL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y80864		Not Available	START SWITCH AND CABLE ASSEMBL
2	Y80863		Not Available	HEX HEAD SCREW
3	Y80830		Not Available	DRAIN PLUG
4	Y80833		Not Available	HOSE CLAMP
5	Y80831		Not Available	RETAINER RING
6	Y80832		Not Available	HOSE
7	80826		Not Available	HOPPER GASKET
8	80842		Not Available	SHREDDER
9	Y00000000		Not Available	SEE NOTE MOTOR ASSEMBLY
10	Y80835		Not Available	LATCH
11	Y80834		Not Available	SOUND SHELL
12	80906		Not Available	RIVET
13	80879		Not Available	LABEL
14	Y80841		Not Available	SHREDDER BUMPER

15	Y80841	Not Available	SHREDDER BUMPER
16	Y80828	Not Available	HEX HEAD SCREW
17	Y80829	Not Available	SPEED NUT
18	Y80825	Not Available	HOPPER

