


Amana HZ1070 05 - LOADING DOOR AND DOOR SAFETY SWITCH



Amana Residential Amana HZ1070 Dryer Parts Parts Diagram 05 - LOADING DOOR AND DOOR SAFETY SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	M540004		Not Available	SCREW
2	M540044		Not Available	SPINDLE
3	M540122		Not Available	PIVOT SCREW
4	M540061		Not Available	PIVOT
5	M540062		Not Available	ACTUATOR
6	53267		Not Available	SPRING
7	52150	489464		Screw
8	Y20278		Not Available	LOCKWASHER
9	M540158		Not Available	BRACKET
10	10484			Switch
11	Y0052975		Not Available	COVER, CONTROL
12	51236	488130		Nut
13	Y00000000		Not Available	SEE NOTE CABINET ASSEMBLY
14	54661	LA-1003		Door Catch Kit
15	M540216		Not Available	CATCH, DOOR xREPLACE
16	M540048W		Not Available	DOOR LINER, WHITE

"	M540048A	Not Available	DOOR LINER, AVOCADO
"	M540048H	Not Available	DOOR LINER, HARVEST GOLD
17	M540009	Not Available	SPEED NUT
18	M540004	Not Available	SCREW
19	M540047	Not Available	HANDLE, DOOR xREPLACE
20	M540046W	Not Available	DOOR PANEL, WHITE
"	M540046A	Not Available	DOOR PANEL, AVOCADO
"	M540046H	Not Available	DOOR PANEL, HARVEST GOLD
21	M540045	Not Available	WASHER

