


Crosley CDE20P8HC 03 - HEATER

SECTION: HEATER
MODEL: CDE20P8C



Issue Date: 2/91

Crosley [Residential Crosley CDE20P8HC Dryer Parts](#) Parts Diagram 03 - HEATER
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0920	LA-1044		Element
"	25-7863			Screw
2	53-1232			Heater Housing Assembly
"	25-7819	M0217225		Screw
3	53-1493			Thermostat
4	53-1181			Bracket, Thermal Fuse
"	25-7741	W10116760		Screw
5	53-0166	53-1518		Block, Terminal
"	25-7803	3400074		Screw
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	25-3122			Washer, Flat
"	25-0027	112432		Nut
6	LA-1053			Fuse Kit, Thermal
"	31001019		Not Available	CORD, POWER