



Magic Chef [Residential Magic Chef CAV1004AWW Washer Parts](#) Parts Diagram 04 - SUPPLEMENTAL INFORMATION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	2206666		Not Available	MANUAL, USE & CARE MAGIC CHEF
"	Y2205348		Not Available	MANUAL, USE & CARE
"	21002059		Not Available	MANUAL, USE & CARE
"	16008333		Not Available	MANUAL, SRVC WASHER- NO REFUND
"	21002078			Harness, Wiring
"	21001919			Harness, Wiring
"	21001980			Lead Assembly
"	21001979			Lead Assembly
"	22003817	3370225		Screw
"	21001592			Cord, Power
"	12002417			Wire Kit
"	16026746		Not Available	TECH SHT, DOM WASHER