


# Magic Chef CYE3004AYW 04 - HEATER



Magic Chef [Residential Magic Chef CYE3004AYW Dryer Parts](#) Parts Diagram 04 - HEATER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001499	<a href="#">LA-1044</a>		Element
"	<a href="#">25-7863</a>			Screw
2	<a href="#">53-1232</a>			Heater Housing Assembly
3	<a href="#">53-0771</a>			Thermostat, Hi-Limit
"	25-3083	<a href="#">212951</a>		Screw, No.6-32 X 1/4 Inch
4	<a href="#">53-0285</a>			Bracket, Thermostat
"	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
5	<a href="#">LA-1053</a>			Fuse Kit, Thermal
6	<a href="#">53-1181</a>			Bracket, Thermal Fuse