


Magic Chef WCZ1050AM 04 - DISPENSER



MODELS COVERED:		From serial Number
a	b	
W10AA-1	W10AN-1	
WCZ1050AM	WCZ1050W	

FIRST PUBLICATION (4-84)

PM-1526-00

REVISION SHEET 0 (4-84)

A-6

Magic Chef [Residential Magic Chef WCZ1050AM Washer Parts](#) Parts Diagram 04 - DISPENSER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	042694		Not Available	SCREW
2	043628		Not Available	SCREW
3	Y043642	414004-35		Screw
4	044219		Not Available	RING
5	064867		Not Available	HOSE CLAMP
6	097034		Not Available	MTG CLIP
7	097061		Not Available	MTG BRKT
8	097070		Not Available	AD KNOB
9	097077		Not Available	RINSE FILTER
10	097086		Not Available	PISTON LEVER
11	097087		Not Available	PISTON
12	097090		Not Available	LEVER EXT
13	097098		Not Available	DETERGENT HOSE
14	097099		Not Available	EXHAUST HOSE
15	097100		Not Available	CONNECTION PIPE
16	097217		Not Available	SLIDE RAIL

17	097264	Not Available	SPRING
18	097351	Not Available	FEELER
19	097864	Not Available	DTRG RECIR HOSE
20	097875	Not Available	AIR INTK CHMBR
21	097961	Not Available	DTRG CONT HANDL
22	098040	Not Available	CLAMP
23	098042	Not Available	CLAMP
24	098330	Not Available	SPRING
25	098331	Not Available	CONTAINER STOP
26	098333	Not Available	DETERGNT DRAWER
27	098336	Not Available	DISP HOUSING
28	098337	Not Available	DISPENSER COVER
29	098914	Not Available	VALVE HOSE
30	098915	Not Available	CLAMP
31	098916	Not Available	CLAMP
32	103595	Not Available	CLAMP

