


# Magic Chef YE14JY1 03 - HEATER

SECTION: HEATER  
MODEL: YE14J(\*)1



Issue Date: 6/90

Magic Chef [Residential Magic Chef YE14JY1 Dryer Parts](#) Parts Diagram 03 - HEATER

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0920	<a href="#">LA-1044</a>		Element
"	<a href="#">25-7863</a>			Screw
2	<a href="#">53-1232</a>			Heater Housing Assembly
"	25-7819	<a href="#">M0217225</a>		Screw
3	<a href="#">53-0771</a>			Thermostat, Hi-Limit
4	<a href="#">53-0285</a>			Bracket, Thermostat
"	25-7741	<a href="#">W10116760</a>		Screw
5	53-0166	<a href="#">53-1518</a>		Block, Terminal
"	25-7803	<a href="#">3400074</a>		Screw
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	<a href="#">25-3122</a>			Washer, Flat
"	25-0027	<a href="#">112432</a>		Nut
6	<a href="#">53-1182</a>			Fuse, Thermal
7	<a href="#">53-1181</a>			Bracket, Thermal Fuse