



[Maytag Residential Maytag 701C Dryer Parts](#) [Parts Diagram 06 - WIRING & CONTROLS](#)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y300059		Not Available	MICRO SWITCH---NA
5	300268			High Limit Thermostat
6	300275		Not Available	WIRE HARNESS, MOTOR
8	300278		Not Available	TERMINAL BLOCK
9	300280		Not Available	WIRE W/TERMINALS
10	300290		Not Available	TIMER
11	300291		Not Available	THERMOSTAT
12	300292		Not Available	LAMP SOCKET
13	300304	303650		Valve-Inlet
14	300314		Not Available	WIRE W/TERMINALS
15	300422		Not Available	WIRE HARNESS
16	300424	3370639		Caster
17	300437		Not Available	WIRE W/TERMINALS
18	300635		Not Available	No.2 WIRE
19	Y301117		Not Available	MOTOR CORD
20	310154		Not Available	TERMINAL FOR MOTOR

21	310289	Not Available	TERMINAL FOR DRUM LIGHT WIRE
22	Y311916	22003781	Screw, Ground Strap
23	200046	Not Available	CONNECTOR, FEMALE
24	200272	Not Available	CONNECTOR, 3 WIRE
25	210175	Not Available	WIRE CONNECTOR
26	211737	248562	Terminal

