



Copyright 1968 THE MAYTAG COMPANY • Newton, Iowa • Printed in U.S.A. (Revised 11-73)

Maytag Residential Maytag DG16CT Dryer Parts Parts Diagram 04 - CT CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
002	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
003	311613	Y311711		Screw, Fuse Block
004	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
005	NLA		Not Available	CAM PLATE ASSEMBLY
006	NLA		Not Available	SWITCH FOR TICKET CONTROL
007	NLA		Not Available	SWITCH ACTUATOR
008	NLA		Not Available	JUMPER WIRE (BLACK)
009	202477	22003292		Control As
010	202479	A3167501		Lamp Oven, Int.
011	202509			Ticket Control Assembly
012	202713	22001555		Fuse
013	203140			Contact Ball Kit
014	NLA		Not Available	FUSE BLOCK WITH FUSE

015	NLA		Not Available	LAMP SOCKET WITH BRACKET
016	NLA		Not Available	HARNES FOR TICKET CONTROL
017	NLA		Not Available	TICKET RECEIVER ASSEMBLY
018	212452			Board, Circuit
019	NLA		Not Available	PIN RECEPTICLE
020	NLA		Not Available	SEMS SCREW (No.4-40 X 1/2 INC)
021	212519	488234		Screw 8-32 X 1/4
022	NLA		Not Available	SCREW, MICRO SWITCH
023	212533			SHIELD FOR HEAT LAMP
024	NLA		Not Available	SCREW, SHIELD TO CONTROL
025	NLA		Not Available	ROLLER FOR CAM
026	NLA		Not Available	FRONT PLATE F/TICKET CONTRO
027	NLA		Not Available	BRACKET FOR TICKET ASSEMBLY
028	NLA		Not Available	TICKET DEFLECTOR
029	NLA		Not Available	SCREW (No.6 X 1/4 INCH)
030	NLA		Not Available	SHIELD

