


Maytag DG31CA 09 - LINT SCREEN-LOWER FRONT



Maytag Residential Maytag DG31CA Dryer Parts Parts Diagram 09 - LINT SCREEN-LOWER FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y055980			Hi-Temp Adhesive, 2 Oz Tube
002	212220	213501		Screw, No.6-20 X 1-1/8 Inch
003	NLA		Not Available	LEVELING LEG
004	Y330071		Not Available	IMPELLER FOR BLOWER
005	Y330078			Cool-Down Bypass Switch
006	Y330086			Lint Screen With Frame
007	331005	701719		Nut, Hex
008	NLA		Not Available	WING NUT, LINT HOOD
009	NLA		Not Available	WASHER, LINT HOOD
010	331031		Not Available	SET SCREW FOR IMPELLER
011	331032	61002031		Screw, Handle
012	331036			Washer-Front Panel Screws
013	331053			Damper
014	NLA		Not Available	HINGE PIN, DAMPER
015	NLA		Not Available	SHIELD, DAMPER SWITCH
016	NLA		Not Available	TWIN FASTENER W/SCREWS

