


# Maytag DG31CM 05 - ACCUMULATOR & COMPONENTS-DOUBLE COIN

## MODEL DG31CM

### CM TIMER ACCUMULATOR & COMPONENTS - SINGLE COIN



- 3-30112 Switch for timer motor
- 3-30113 Timer motor
- 3-30116 Timing cam kit - 7-1/2 min. - 8 pins on cam
- 3-30117 Timing cam kit - 10 min. - 6 pins on cam
- 3-30145 Timer accumulator complete - .10
- 3-30162 Switch for time delay
- 3-30163 Coin handling mechanism
- 3-30164 Meter plate assembly
- 3-30165 Coin retainer spring and screw kit
- 3-31118 Coil spring for pawl
- 3-31121 Coil spring for detent arm
- 3-31122 Index lever and switch actuator
- 3-31147 Coil spring for coin carrier return

8

#### Maytag Residential Maytag DG31CM Dryer Parts Parts Diagram 05 - ACCUMULATOR & COMPONENTS-DOUBLE COIN

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TIMER ACCUMULATOR - CM
002	<a href="#">330112</a>			Switch For Actuator
003	<a href="#">330113</a>			Timer Motor
004	NLA		Not Available	METER PLATE ASSEMBLY
005	NLA		Not Available	COIN HANDLING ASSEMBLY
006	330116		Not Available	TIMING CAM - 8 PINS
007	330117		Not Available	TIMING CAM - 6 PINS
008	NLA		Not Available	COIL SPRING FOR PAWL
009	NLA		Not Available	SIDE SPRING-COIN RETAINER
010	NLA		Not Available	BOTTOM SPRING-COIN RETAINER
011	NLA		Not Available	COIL SPRING FOR DETENT ARM
012	NLA		Not Available	INDEX LEVER-SWITCH ACTUATOR
013	<a href="#">331153</a>			Coil Spring F/Carrier Retur