


Maytag DG32CM 11 - LINT SCREEN-LOWER FRONT



Maytag Residential Maytag DG32CM Dryer Parts Parts Diagram 11 - LINT SCREEN-LOWER FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y054866	486009		Lockwasher
002	Y055980			Hi-Temp Adhesive, 2 Oz Tube
003	212220	213501		Screw, No.6-20 X 1-1/8 Inch
004	NLA		Not Available	LEVELING LEG
005	Y330071		Not Available	IMPELLER FOR BLOWER
006	Y330078			Cool-Down Bypass Switch
007	Y330086			Lint Screen With Frame
008	331005	701719		Nut, Hex
009	NLA		Not Available	WING NUT, LINT HOOD (CAB.)
010	NLA		Not Available	WASHER, LINT HOOD (CABINET)
011	331031		Not Available	SET SCREW FOR IMPELLER
012	331032	61002031		Screw, Handle
013	331036			Washer-Front Panel Screws
014	331053			Damper
015	NLA		Not Available	HINGE PIN, DAMPER

016	NLA	Not Available	SHIELD, DAMPER SWITCH
017	210866		Nut, Twin Speed
018	NLA	Not Available	TWIN FASTENER W/SCREWS

