


# Maytag DG32CT 12 - LINT SCREEN-LOWER FRONT



Maytag [Residential Maytag DG32CT Dryer Parts](#) Parts Diagram 12 - LINT SCREEN-LOWER FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y054866	<a href="#">486009</a>		Lockwasher
002	<a href="#">Y055980</a>			Hi-Temp Adhesive, 2 Oz Tube
003	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
004	NLA		Not Available	LEVELING LEG
005	Y330071		Not Available	IMPELLER FOR BLOWER
006	<a href="#">Y330078</a>			Cool-Down Bypass Switch
007	<a href="#">Y330086</a>			Lint Screen With Frame
008	331005	<a href="#">701719</a>		Nut, Hex
009	NLA		Not Available	WING NUT, LINT HOOD (CAB.)
010	NLA		Not Available	WASHER, LINT HOOD (CABINET)
011	331031		Not Available	SET SCREW FOR IMPELLER
012	331032	<a href="#">61002031</a>		Screw, Handle
013	<a href="#">331036</a>			Washer-Front Panel Screws
014	<a href="#">331053</a>			Damper
015	NLA		Not Available	HINGE PIN, DAMPER

016	NLA	Not Available	SHIELD, DAMPER SWITCH
017	<a href="#">210866</a>		Nut, Twin Speed
018	NLA	Not Available	TWIN FASTENER W/SCREWS

