


Maytag LAT5004BGW 05 - TOP



Maytag [Residential Maytag LAT5004BGW Washer Parts](#) Parts Diagram 05 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211726			Hinge, Ball Lid
2	207159	489355		Screw, 8 X 1/2
"	22001298			Cap, Top Cover
3	207167			Block, Fuse
4	216256		Not Available	BRACKET, UNBALANCE
5	207166			Switch, Check
6	205635			Console
7	213720			Spring, Lid Switch
8	216183			Grommet, Cord Export
9	215075			Fastener, Control Panel To Console
10	207168	22001682		Switch Assembly, Lid W/4amp Fuse
11	22001136			Lever, Unbalance
12	301548			Clamp, Ground Wire
13	22001387		Not Available	CHANNEL ASSY.
14	22001206	22001893		Lid

15	212716		Bumper, Lid
16	205415	279347	Switch-Lid
17	216255		Plunger, Lid Switch
18	211500		Washer, Bracket To Top Cover
19	Y215699	22001678	Bracket, Switch And Fuse
20	208746	Not Available	CORD, POWER (EXPORT)
21	204445		Screw And Fastener Assembly
22	207159	489355	Screw, 8 X 1/2
23	210186	3370225	Screw
24	Y313559		Screw
"	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
25	213501		Screw, No.6-20 X 1-1/8 Inch
26	Y311711		Screw, Fuse Block
27	Y313559		Screw
28	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
29	22001352		Screw, Check Switch
30	22001117	Not Available	TOP COVER ASSEMBLY (WHT)
31	22001311		Unbalance Lever Assembly
34	207176	22001682	Switch Assembly, Lid W/4amp Fuse

