


## Maytag LAT5005ABW 04 - CONTROL PANEL



Maytag [Residential Maytag LAT5005ABW Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001132</a>			Plate, Support
"	315483	<a href="#">3370225</a>		Screw
"	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
3	216193		Not Available	CAP, TIMER KNOB (BLK)
4	410296	<a href="#">596669</a>		Clamp, Manifold
5	<a href="#">22001030</a>			Panel, Control
6	<a href="#">214897</a>			Pad, Control Panel
7	<a href="#">22001267</a>			Knob, Selector Switch
8	<a href="#">207927</a>			End Cap, Control Panel
"	207928		Not Available	END CAP, CTRL. PNL. (LT-BLK)
9	<a href="#">214894</a>			Fastener, End Cap
10	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
11	<a href="#">211605</a>			Bezel, Timer Dial

12	314728	<a href="#">210932</a>	Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
14	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
15	<a href="#">216412</a>		Screw, Bracket To Timer
16	<a href="#">22001316</a>		Wire Harness, Main
17	22001515	Not Available	MOTOR, TIMER
"	<a href="#">22001530</a>		Timer Can
18	22001264	Not Available	BEZEL, TIMER KNOB (BLK)
19	<a href="#">215828</a>		Knob, Timer
20	<a href="#">211065</a>		Spring, Index Wheel
21	208205	Not Available	SWITCH, PRESSURE
22	22001108	Not Available	MANUAL, USE & CARE
"	208283	Not Available	SWITCH, WATER TEMPERATURE
23	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
"	22001107	Not Available	MANUAL, USE & CARE

