


Maytag LAT6914AAM 04 - CONTROL PANEL (LAT8904AAM & LAT6914AAM)



Maytag Residential Maytag LAT6914AAM Washer Parts Parts Diagram 04 - CONTROL PANEL (LAT8904AAM & LAT6914AAM)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	204807			Ground Wire, Supp. Plte To Top Cover
"	22001133			Plate, Support
"	315483	3370225		Screw
3	216424		Not Available	CAP, KNOB (ALM)
4	410296	596669		Clamp, Manifold
5	22001467		Not Available	PANEL, CONTROL (ALM)
6	214897			Pad, Control Panel
7	22001215	7730P011-60		Lens, Indicator Light
8	22001293			End Cap, Control Panel
"	22001292	22001567		Cap, End
"	22001567			Cap, End
"	22001566	22001293		End Cap, Control Panel
9	214894			Fastener, End Cap

10	214872		Palnut, End Cap Note: Nut, Lamp Holder
11	211605		Bezel, Timer Dial
12	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210	Screw, 8-18 X 5/16
14	22001282	22001135	Switch, Rocker
15	216412		Screw, Bracket To Timer
16	903115		Lock Light
17	22001024		Timer
18	22001266	Not Available	BEZEL, TIMER KNOB (ALM)
19	22001199	Not Available	KNOB ASSY. (ALM)
20	211065		Spring, Index Wheel
21	22001454	Not Available	SWITCH, INFINITE (ALM)
22	22001455	Not Available	SWITCH, WATER TEMP. (ALM)
23	22001338		Wire Harness, Main
25	22001094		Manual, Use And Care
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

