

# Maytag LAT7304AAE 06 - TRANSMISSION



Maytag Residential Maytag LAT7304AAE Washer Parts Parts Diagram 06 - TRANSMISSION  
 Click on the part number to view part

| Item | Original Part Number    | Replaced By               | Status        | Part Description                 |
|------|-------------------------|---------------------------|---------------|----------------------------------|
| 1    | <a href="#">206628</a>  |                           |               | Cover, Transmission              |
| 2    | 207153                  | <a href="#">6-2097820</a> |               | Kit- Shaft                       |
| 3    | 206713                  | <a href="#">6-2067130</a> |               | Gear- Beve                       |
| 4    | 215411                  | <a href="#">12001451</a>  |               | Ctr Shaft W/Collar Andkeeper-Sha |
| 5    | 215415                  |                           | Not Available | COLLAR, LOWER                    |
| 6    | 206625                  | <a href="#">6-2097790</a> |               | Transmison                       |
| 7    | <a href="#">215394</a>  |                           |               | Washer, Bevel Gear               |
| 8    | 211059                  | <a href="#">6-2301530</a> |               | Pulley                           |
| 9    | 211483                  | <a href="#">6-2114830</a> |               | Washer- SP                       |
| 10   | 206602                  | <a href="#">207843</a>    |               | Lip Seal Repair Kit              |
| 11   | <a href="#">Y206629</a> |                           |               | Pin, Collar                      |
| 12   | 215401                  | <a href="#">W10221114</a> |               | Pinion                           |
| 13   | <a href="#">215395</a>  |                           |               | Plate, Clutch                    |
| 14   | 211090                  | <a href="#">22003555</a>  |               | Washer, Stop Lug                 |
| 15   | 211375                  | <a href="#">681582</a>    |               | Screw                            |
|      |                         |                           |               | SCREW, TRANSMISSION              |

|    |                        |                           |                           |
|----|------------------------|---------------------------|---------------------------|
| 16 | 215417                 | Not Available             | SCREW, TRANSMISSION COVER |
| 17 | <a href="#">210690</a> |                           | Seal, Rubber              |
| 18 | Y058700                | <a href="#">675652</a>    | Adhesive                  |
| 19 | <a href="#">215581</a> |                           | Spring, Agitator Shaft    |
| 20 | <a href="#">211089</a> |                           | Lug, Stop Pulley          |
| 21 | 206685                 | <a href="#">6-2066850</a> | Yoke                      |
| 22 | 206708                 | <a href="#">6-2097790</a> | Transmison                |

