


Maytag LDG31CA 06 - DOOR SWTCH, TEMP CNTRL, & TERMINAL BLOCK

MODEL DG31CA-CM-CT

DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK



12

Maytag Residential Maytag LDG31CA Dryer Parts Parts Diagram 06 - DOOR SWTCH, TEMP CNTRL, & TERMINAL BLOCK

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
002	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	210866			Nut, Twin Speed
004	212220	213501		Screw, No.6-20 X 1-1/8 Inch
005	212951			Screw, No.6-32 X 1/4 Inch
006	NLA		Not Available	CLIP - ACTUATOR TO CABINET
007	Y330077			Door Switch
008	Y330078			Cool-Down Bypass Switch
009	Y330083		Not Available	CONTROL, TEMPERATURE
010	Y330087			Drum Assembly Complete
011	Y330092			Terminal Block
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-ALMOND
014	NLA		Not Available	FRONT PANEL-HARVEST

014	NLA	Not Available	WHEAT
015	Y330100	Not Available	COIN BOX ASSEMBLY
016	Y330147		Part Not Used
017	NLA	Not Available	VAULT ASSEMBLY
018	NLA	Not Available	SCREW - BRACKET TO VAULT
019	331012	400022-1	Screw
020	331014	8281196	Screw
021	331026	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
022	NLA	Not Available	SQUARE WASHER FOR DRUM ROD
023	331058		Grommet-Temp. Control Tubin
024	331061		Knob For Temperature Contro
025	NLA	Not Available	MOUNTING PLATE-DOOR SWITCH
026	NLA	Not Available	DRUM ROD
027	NLA	Not Available	ACTUATOR FOR DOOR SWITCH
028	NLA	Not Available	SCREW-TEMP CONTROL LEVER
029	NLA	Not Available	BRACKET-TEMPERATURE CONTROL
030	331151		Lever-Temperature Control
031	NLA	Not Available	NUT FOR CONDUIT
032	331230		Clip
033	NLA	Not Available	TWIN FASTENER WITH SCREWS

